




ADC Operation Manual



Index

| | |
|---|----|
| 1. Installation | 3 |
| 1.1 Required PC specification | 3 |
| 1.2 Software | 3 |
| 2. Operation | 3 |
| 2.1 Connection | 3 |
| 2.2 Menu | 3 |
| 2.2.1 System | 5 |
| 2.2.2 Settings | 6 |
| 1) Fastening | 6 |
| 2) I/O | 7 |
| 3) Screw count | 11 |
| 4) Advanced function | 12 |
| 5) Controller 1 & 2 | 13 |
| 6) Multi sequence | 14 |
| 7) Model setting | 16 |
| 2.2.3 Monitoring | 19 |
| 1) Real-time monitoring | 19 |
| 2) Graph monitoring | 20 |
| 3) Remote control & I/O status monitoring | 20 |
| 4) Process capability monitoring | 21 |
| 5) Auto Customizing | 22 |
| 6) Error history | 24 |
| 7) Synchronizing fastening by torque | 25 |
| 3. Error & system alarm code | 27 |
| 3.1 System error | 27 |
| 3.2 Fastening error | 28 |
| 3.3 System alarm | 30 |

1. Software installation

1.1 Required PC specification

- OS : Windows 7 or later version

1.2 Software

- Software file : ParaMon v0.00 yyyyymmdd.zip
- Install file : setup.exe

The higher version of software will overwrite the lower version of ParaMon software.

2. Operation


2.1 Connection

ParaMon pc software have 4 selectable connecting options to the MDC or ADC controller.

MDC controller : Serial RS232C or Ethernet

ADC drive : Serial RS422 or USB Serial COM port


connection requires the information about COM port, Baud rate and the device ID






2.2 Menu

There are 3 main menu.

- System
- Settings
- Monitoring






Be sure that the changed parameter on the ParaMon pc software is reflected to the ADC drive immediately.

2.2.1 System

1) Firmware downloader


Drive firmware can be replaced by the below process. Use **USB port only**. **Ethernet is not allowed for firmware download.**



- 1) Disconnect USB connection of ParaMon from the Drive.
- 2) Click " Firmware Downloader "
- 3) Click " Load " on the pop-up window, and select the firmware file on the pc.
- 4) Click " Start "
- 5) See the message " Firmware upload complete " in the message window, and click " Close " to finish the process.
- 6) Turn the power of the controller OFF, and ON again to initialize the settings

2.2.2 Settings

1) Fastening




There are 15 preset groups for fastening setting. Each preset # consists of torque, speed, Min & Max angle for fastening OK range, soft start, Free speed before tightening.


- Control type : TC/AM or AC/TM
(torque control angle monitoring or angle control torque monitoring)
- Torque : Target torque
- Torque limit (%) : OK torque range in AC/TM mode
- Target angle : Target angle in AC/TM mode
- Min angle (degree) : Minimum angle to be OK in TC/AM mode
- Max angle (degree) : Maximum angle to be OK in TC/AM mode
- Snug torque(%) : Point (% from target torque) to start monitoring angle in TC/AM mode
- Speed : Target speed. Speed is changed by torque setting automatically. To change manually, Auto Speed

must be Disabled in Control 2

- Free speed : Manual setting speed. Shift back to the auto speed after the free angle running
- Free angle : Angle for Free speed.
- Soft start(mS) : Speed reach to the target in the setting time
- Seating point(%) : Auto speed slow down to ramp-up speed for torque control
- Torque rising time(mS) : Time setting from seating point to the target
- Torque holding time(mS) : Target torque holding time
- Torque compensation(%) : Preset # has each torque compensation value.



2) Input / Output management



The digital I/O provide the free assignment feature for Input and Output.

Factory setting of I/O assignments are as following.

To validate changing I/O, turn the power OFF and ON again.

◆ Digital I/O mapping factory setting

| Description | Digital Input | Description | Digital Output |
|-----------------|---------------|----------------|----------------|
| Preset select 1 | Input 1 | Torque up | Output 1 |
| Preset select 2 | Input 2 | Fastening OK | Output 2 |
| Preset select 3 | Input 3 | Ready | Output 3 |
| Start | Input 4 | Motor Run | Output 4 |
| Fasten / Loosen | Input 5 | Alarm | Output 5 |
| Lock | Input 6 | Status For/Rev | Output 6 |
| Multi sequence | Input 7 | Count Complete | Output 7 |
| Reset | Input 8 | Alarm 1 | Output 8 |
| Count Start | - | Alarm 2 | |
| Count Reset | - | Alarm 3 | |
| Count Out | - | Sync Out | |
| Preset select 4 | - | Model Complete | |
| Sync In | - | | |
| Sync resume | - | | |
| CW Lock | - | | |
| CCW Lock | - | | |
| Model Cancel | - | | |

◆ ADC 50P I/O details

| 50P I/O pin no. | Description | Factory setting |
|-----------------|------------------|-------------------|
| 11, 21 | <i>IN COM</i> | |
| 12 | IN 1 | Preset select 1 |
| 13 | IN 2 | Preset select 2 |
| 14 | IN 3 | Preset select 3 |
| 15 | IN 4 | Start |
| 16 | IN 5 | Forward / Reverse |
| 17 | IN 6 | Driver Lock |
| 18 | IN 7 | Multi sequence |
| 19 | IN 8 | Reset |
| 22 | IN 9 | - |
| 23 | IN 10 | - |
| 24 | IN 11 | - |
| 25 | IN 12 | - |
| 26 | IN 13 | - |
| 27 | IN 14 | - |
| 28 | IN 15 | - |
| 29 | IN 16 | - |
| 35 | OUT 1 (+) | Torque UP |
| 36 | <i>OUT 1 (-)</i> | |
| 37 | OUT 2 (+) | Fastening OK |
| 38 | <i>OUT 2 (-)</i> | |
| 39 | OUT 3 (+) | Ready |
| 40 | <i>OUT 3 (-)</i> | |
| 41 | OUT 4 (+) | Motor RUN |
| 42 | <i>OUT 4 (-)</i> | |
| 43 | OUT 5 (+) | Alarm |
| 44 | <i>OUT 5 (-)</i> | |
| 45 | OUT 6 (+) | Status F/L |
| 46 | <i>OUT 6 (-)</i> | |
| 47 | OUT 7 (+) | Count complete |
| 48 | <i>OUT 7 (-)</i> | |
| 49 | OUT 8 (+) | |
| 50 | <i>OUT 8 (-)</i> | |

Connector model : 3M MDR10250-52A2PL


◆ Binary coding with 5 inputs to select preset #

| Preset # | Input | | | | |
|----------|-----------------|-----------------|-----------------|-----------------|----------------|
| | Preset select 4 | Preset select 3 | Preset select 2 | Preset select 1 | Multi sequence |
| 1 | 0 | 0 | 0 | 1 | |
| 2 | 0 | 0 | 1 | 0 | |
| 3 | 0 | 0 | 1 | 1 | |
| 4 | 0 | 1 | 0 | 0 | |
| 5 | 0 | 1 | 0 | 1 | |
| 6 | 0 | 1 | 1 | 0 | |
| 7 | 0 | 1 | 1 | 1 | |
| 8 | 1 | 0 | 0 | 0 | |
| 9 | 1 | 0 | 0 | 1 | |
| 10 | 1 | 0 | 1 | 0 | |
| 11 | 1 | 0 | 1 | 1 | |
| 12 | 1 | 1 | 0 | 0 | |
| 13 | 1 | 1 | 0 | 1 | |
| 14 | 1 | 1 | 1 | 0 | |
| 15 | 1 | 1 | 1 | 1 | |
| Multi A | 0 | 0 | 0 | 1 | 1 |
| Multi B | 0 | 0 | 1 | 0 | 1 |

◆ Binary coding with 3 outputs for error codes in 7 groups


| Error code | Alarm 3 | Alarm 2 | Alarm 1 |
|-------------------------------------|---------|---------|---------|
| 110,113,114,115,116,118,200,201,220 | 0 | 0 | 1 |
| 300,301,302,303,304,309 | 0 | 1 | 0 |
| 310,311 | 0 | 1 | 1 |
| 330,337 | 1 | 0 | 0 |
| 332,338 | 1 | 0 | 1 |
| 333,334,335,336 | 1 | 1 | 0 |
| AL-xx Alarm (System alarm) | 1 | 1 | 1 |

3) Screw count



Total count number

Middle count number




◆ Count start signal (IN)

- 1) No signal, auto start (Auto) - auto reset to total number after "0"
- 2) Sensor or switch with one trigger pulse - Count starts with only trigger pulse. Counting is valid until complete or reset. Reset calls count NG
- 3) One trigger pulse with timer for counting - Counting should be completed within the time of timer from the trigger pulse, otherwise count NG
- 4) One trigger pulse to start counting, another trigger pulse to stop counting and evaluate OK or NG. Any remaining number calls count NG

◆ Count complete signal (OUT)

If mid count number is used, count complete signal out is provided on mid count number and reset on the cycle completed.

4) Advanced functions



There are 4 steps of Advanced Function to customize the screw fastening process.

Step 1 (Option) : Free Reverse rotation to guide the screw into the screw hole smoothly with low speed

Step 2 (Option) : Engaging torque detection – The monitoring angle count is reset and start again from the engaging torque detection point which the screw start joining the thread. It is possible only when the screw engaging provide significantly higher torque than previous free run. Engaging torque setting is by percentage of target torque.

Step 3 (Preset) : Free Speed – The system auto speed by torque setting can be manually replaced to have higher or lower speed than it's original auto speed during the limited angle setting. Be sure that the free speed run should stop before the screw seating point which screw start to tightening joint. To use this option, go the Fastening setting menu.

Step 4 (Preset) : Fastening sequence – have the important parameter factors to the tightening quality.


1) Seating point (%) : It is trash hold point at that the target speed is shifting to torque up process. The factory setting is guided from hard joint. If the it is soft joint, the setting can be higher percentage of the target torque.

2) Torque rising time(mS) : It is the speed and time during ramp-up to the target torque. Quick or slow speed to the target torque according to the condition.

3) Torque holding time(mS) : Tool holds the target torque for the time setting. It stabilizes the tightening condition.

Step 5 (Option) : Angle after torque-up(A261) : It manage extra angle control in both forward or reverse direction after tightening by torque.

5) Controller 1 & 2



Forward / Reverse motor RUN time, and motor stall time is limited for motor safety. The following parameters is ideally recommended to be kept with factory setting in all application.

- Forward RUN time limit (A270) : Run limit to forward rotation
- Reverse RUN time limit (A271) : Run limit to reverse rotation
- Motor Stall time limit (A272)
- Acceleration (A274) : Slow start of motor to the target speed
- **Auto speed (A290) : ENABLE** provide the safe speed on the torque setting
- Driver model no.(A281) : not changeable. Auto recognized

Other parameters are selectable and changeable for application requirements.

- Torque unit (A301) : Kgf.cm / Kgf.m / cNm / Nm / ozf.in / lbf.in / lbf.ft Whenever the unit is changed, the controller should be reboot again
- Fastening stop error (A293) : DISABLE does not creat any NG when the tool stop without torque up fully tightening.

6) Multi sequence

The screenshot shows the ParaMon - Parameter & Remote control software interface. The main window has a blue header with the title "ParaMon - Parameter & Remote control" and standard window controls. Below the header is a navigation bar with tabs: "System", "Settings", and "Monitoring". The "Settings" tab is active. Under the "Settings" tab, there are several icons representing different settings categories: Fastening, Input / Output, Screw Count, Advanced Function, Controller1, Controller2, Multi Sequence, Network, Backup, and Restore. The "Multi Sequence" icon is highlighted. Below the navigation bar, the main content area is divided into two panels. The left panel, titled "Parameter settings", contains three sections: "Controller information" (Model: MDC26, Version: 0.81.6), "Driver information" (Model: MD2616, Serial no.: 16.11.0005), and "Software information" (Version: v1.1.5, Release: 2016.11.15). The right panel, titled "Multi Sequence Setting", contains a "Mode" dropdown menu and a table with columns "Step No", "Command", and "Parameter". The table is divided into two sections: "Mode: Mode A" and "Mode: Mode B".

| Step No | Command | Parameter |
|---------------------|---------|-----------|
| Mode: Mode A | | |
| Step01 | NOP | 0 |
| Step02 | NOP | 0 |
| Step03 | NOP | 0 |
| Step04 | NOP | 0 |
| Step05 | NOP | 0 |
| Step06 | NOP | 0 |
| Step07 | NOP | 0 |
| Step08 | NOP | 0 |
| Step09 | NOP | 0 |
| Step10 | NOP | 0 |
| Mode: Mode B | | |
| Step01 | NOP | 0 |
| Step02 | NOP | 0 |
| Step03 | NOP | 0 |
| Step04 | NOP | 0 |

◆ Command details

| Command | Description |
|-----------------|--|
| NOP | No operation |
| Fastening | tool start fastening process in forward rotation |
| Loosening | tool start loosening process in reverse rotation |
| Select preset# | Select preset # |
| Delay | time delay for setting time |
| Jump | Move to the setting step |
| Count value = A | Total number "A" to count |
| Sub if (A) | Subtract 1 from "A" and save the value replacing "A" . If the value "A" is not "0", then move to the next lower step. If the value "A" is "0", then move to 2 nd lower step |
| End | Finish multi-sequence process |

Multi sequence provide a cycle of fastening by a start signal.

Total 10 steps of programing is allowed in MA(Multi A) and MB(Multi B) presets

To program, select the command and required parameter on each step.

To finish the multi sequence programing, last step command should be "END"

[Example of Multi sequence step program]

| Setp no | Command | Parameter |
|---------|-----------------|-----------|
| Step 1 | Count Value = A | 10 |
| Step 2 | Select Preset# | 1 |
| Step 3 | Fastening | |
| Step 4 | Loosening | 5 |
| Step 5 | Select Preset# | 3 |
| Step 6 | Fastening | |
| Step 7 | Sub if (A) | |
| Step 8 | Jump | 2 |
| Step 9 | End | |

Step 1 : Total counting number is 10

Step 2 : Preset #1 selected and move to the next step

Step 3 : Start fastening and stop by torque or angle setting, and move to the next step

Step 4 : Loosen 5 turns and move to the next step

Step 5 : Preset #3 selected and move to the next step

Step 6 : Start fastening and stop by torque or angle setting, and move to the next step

Step 7 : Subtract 1 from "10" and save "9" by replacing "10". If the value "A" is not "0", then move to the next lower step. If the value "A" is "0", then move to 2nd lower step

Step 8 : Jump to step no. 2

Step no.2 to Step no. 6 works for a cycle. Total 10 cycles are operated automatically by a start signal. Any failure or NG on each step, Multi-sequence process stops and provide the alarm signal.

7) Models

It provides sequential screw tightening with screw counting feature together with I/O and time delay managing by programming in 10 steps.

There are 4 different type of command – Input, Output, Fastening and Time delay

Each step can have one of the above four commands with related setting value

The fastening with counting number follows all settings and features in Screw Count menu except the number of screw.


There are total 15 programmable Models.

Once Model is selected, the digital inputs for preset # select becomes model # select automatically.

To use Model feature, select Enable on the menu of Controller 2 - Model select (A292).

The spindle can be locked automatically in all steps except Fastening step, by selecting

Enable on the menu of Controller 1 – Automatic driver lock (A284)



◆ Command details

| Command | Description | Data 1 | Data 2 |
|-----------|------------------------|-------------------------------|---|
| Input | Mapping digital Input | Input # select from 1 - 16 | 0 : No output → NG 1 : Active High 2 : Active Low 3 : High status 4 : Low status |
| Output | Mapping digital Output | Output # select from 1 - 8 | 0 : No Output → NG 1 : On 2 : Off 3 : On for 0.5s and Off 4 : On for 1.0s and Off |
| Fastening | Start fastening | Preset # from 1 - 15 | Count number from 1 - 250 |
| Delay | Delay time | - | 0.1 - 25 sec. (unit: 0.1s) |

[Example of Model programing]

| Step | Command | Data 1 | Data 2 | Description |
|--------|-----------|--------|--------|---|
| Step 1 | Input | 5 | 1 | If there is input signal turning on in Input no.5, then move to the next step |
| Step 2 | Fastening | 2 | 3 | Fastening total 3 screws with preset# 2. If fastening of all screws are completed, then moves to the next step. If there is the cycle start condition except "Auto" on the menu of Screw Count, counting will start only with the cycle start signal input. And if the workpiece is removed without complete of count number, Model process can be stopped by Model cancel (input). Refer 3) Screw Count on the manual |
| Step 3 | Delay | - | 0.5 | Delay for 0.5 seconds. Then move to the next step |
| Step 4 | Output | 2 | 3 | Provide 0.5s pulse ON signal output in Output # 2. Then move to the next step. |
| Step 5 | Fastening | 3 | 5 | Fastening total 5 screws with preset# 3. Then moves to the next step. Screw counting condition is same as Step 2 |
| Step 6 | Output | 3 | 4 | Provide 1.0s pulse ON signal output in Output # 2. Then move to the next step. |



Step 1 : Read the sensor signal when it detect the workpiece loading

- Connect sensor to Digital Input 5 (pin no.16)
- I/O setting → Input 5 : None



Step 2 : Screw tightening with Preset #2

Number of screw = 3



Step 4 : Provide output signal for 0.5 seconds

- Connect buzzer to Digital Output 2 (pin no. 37 & 38)
- I/O setting → Output 2 : None



Step 5 : Screw tightening with Preset #3

Number of screw = 5



Step 6 : Provide output signal for 0.5 seconds

- Connect buzzer to Digital Output 3 (pin no. 39 & 40)
- I/O setting → Output 3 : None

2.2.3 Monitoring

1) Real-time monitoring

Setting of Auto Data Out (A297) should be " Disable " for Monitoring

The screenshot shows the 'ParaMon - Parameter & Remote control' application window. The 'Monitoring' tab is active, displaying 'Real Time Monitoring'. The left sidebar contains 'Connectors' (Model: MDC3626, Version: 0.81.0) and 'Information' (Model: MD2616, Serial no.: 16.11.0005, Software information: Version v1.1.4, Release 2016.11.09). The main area shows a table with 15 columns: Number, Time, Fasten..., Preset, T/Tor..., C/Tor..., Speed, Angle 1, Angle 2, Angle, Error, Count, F/L, and Status. The table contains 19 rows of data. At the bottom, there are 'Save', 'Clear', and 'Stop' buttons, and a status bar indicating 'Connected' and 'Log history'.

| Number | Time | Fasten... | Preset | T/Tor... | C/Tor... | Speed | Angle 1 | Angle 2 | Angle | Error | Count | F/L | Status |
|--------|----------|-----------|--------|----------|----------|-------|---------|---------|-------|-------|-------|-----|--------|
| 3 | 13:51... | 752 | 1 | 5 | 4.92 | 118 | 1.24 | 0.04 | 1.28 | 0 | 4 | 1 | 1 |
| 4 | 13:51... | 799 | 1 | 5 | 5.01 | 118 | 1.33 | 0.03 | 1.36 | 0 | 3 | 1 | 1 |
| 5 | 13:51... | 1201 | 1 | 5 | 5.04 | 118 | 1.25 | 0.48 | 1.73 | 0 | 2 | 1 | 1 |
| 6 | 13:51... | 841 | 1 | 5 | 5.01 | 118 | 1.41 | 0.03 | 1.44 | 0 | 1 | 1 | 1 |
| 7 | 13:51... | 804 | 1 | 5 | 4.99 | 118 | 1.34 | 0.02 | 1.37 | 0 | 5 | 1 | 1 |
| 8 | 13:51... | 788 | 1 | 5 | 5.03 | 118 | 1.31 | 0.02 | 1.34 | 0 | 4 | 1 | 1 |
| 9 | 13:51... | 767 | 1 | 5 | 4.98 | 118 | 1.27 | 0.02 | 1.3 | 0 | 3 | 1 | 1 |
| 10 | 13:51... | 819 | 1 | 5 | 5.03 | 118 | 1.37 | 0.03 | 1.4 | 0 | 2 | 1 | 1 |
| 11 | 13:51... | 811 | 1 | 5 | 4.97 | 118 | 1.35 | 0.03 | 1.38 | 0 | 1 | 1 | 1 |
| 12 | 13:51... | 781 | 1 | 5 | 5.01 | 118 | 1.29 | 0.02 | 1.32 | 0 | 5 | 1 | 1 |
| 13 | 13:51... | 758 | 1 | 5 | 5.03 | 118 | 1.25 | 0.02 | 1.28 | 0 | 4 | 1 | 1 |
| 14 | 13:51... | 767 | 1 | 5 | 5.04 | 118 | 1.27 | 0.02 | 1.3 | 0 | 3 | 1 | 1 |
| 15 | 13:51... | 758 | 1 | 5 | 4.97 | 118 | 1.25 | 0.02 | 1.28 | 0 | 2 | 1 | 1 |
| 16 | 13:51... | 841 | 1 | 5 | 5.11 | 118 | 1.42 | 0.03 | 1.46 | 0 | 1 | 1 | 1 |
| 17 | 13:51... | 731 | 1 | 5 | 5.01 | 118 | 1.2 | 0.02 | 1.22 | 0 | 5 | 1 | 1 |
| 18 | 13:51... | 739 | 1 | 5 | 5.04 | 118 | 1.21 | 0.03 | 1.25 | 0 | 4 | 1 | 1 |
| 19 | 13:51... | 746 | 1 | 5 | 5.01 | 118 | 1.22 | 0.02 | 1.25 | 0 | 3 | 1 | 1 |

The following data are monitored automatically on every event as like motor run, torque up, Forward / Reverse change, preset # change, etc.


- Date & time
- Fastening time
- Preset #
- Target torque
- Converted torque
- Speed
- Angle 1 (angle from motor start to screw seating point)
- Angle 2 (angle from screw seating point to the end)
- Angle 3 (Angle 1 + Angle 2)
- Snug Angle(degree) : angle from snug torque to the end
- Error code
- Screw count no.
- Forward / Reverse status
- Status (OK, NG)

The monitoring data can be saved in CSV file. And it can open the file.

2) Graph monitoring

Total 200 real-time data are displayed with curve together in two channel.

- Torque, Speed, Angle(degree), Angle(turn) and current
- Data sampling rate : 5ms (1s), 10ms(2s), 15ms(3s)
- Data display option : Fastening, Loosening, All



The monitoring data can be saved in CSV file. And it can open the file.


3) Remote control & I/O status monitoring

The tool is operated remotely for the followings.

- Fastening / loosening rotation,
- Tool Start
- Tool lock & unlock

The following main signal status and I/O are monitored and displayed together with torque, speed and current curves.


- Ready, Tool start/stop, Torque up, Fastening OK, Alarm, F/R, I/O



4) Process capability display

From real-time monitoring fastening torque data, the following statistical data are calculated and displayed. The data is updated automatically for every fastening until monitoring cancelled.

- Average, Standard deviation, CP, CPK



Process capability analysis


| No. | FastenTime | P... | T/Torque | C/Torque | Speed | Angle | Error | Status |
|-----|------------|------|----------|----------|-------|-------|-------|--------|
| 1 | 553 | 1 | 2 | 1.99 | 620 | 0.31 | 0 | 1 |
| 2 | 467 | 1 | 2 | 1.97 | 620 | 3.61 | 0 | 1 |
| 3 | 501 | 1 | 2 | 1.97 | 620 | 3.54 | 0 | 1 |
| 4 | 479 | 1 | 2 | 2.02 | 620 | 3.66 | 0 | 1 |
| 5 | 462 | 1 | 2 | 1.92 | 620 | 3.43 | 0 | 1 |
| 6 | 473 | 1 | 2 | 1.98 | 620 | 3.52 | 0 | 1 |
| 7 | 508 | 1 | 2 | 2.04 | 620 | 3.66 | 0 | 1 |
| 8 | 456 | 1 | 2 | 2 | 620 | 3.32 | 0 | 1 |
| 9 | 491 | 1 | 2 | 2.03 | 620 | 3.54 | 0 | 1 |
| 10 | 475 | 1 | 2 | 1.99 | 620 | 3.64 | 0 | 1 |
| 11 | 450 | 1 | 2 | 1.93 | 620 | 3.32 | 0 | 1 |
| 12 | 487 | 1 | 2 | 2 | 620 | 3.73 | 0 | 1 |
| 13 | 392 | 1 | 2 | 2 | 620 | 2.78 | 0 | 1 |
| 14 | 387 | 1 | 2 | 1.99 | 620 | 2.73 | 0 | 1 |
| 15 | 419 | 1 | 2 | 2.07 | 620 | 3.01 | 0 | 1 |
| 16 | 412 | 1 | 2 | 2.03 | 620 | 2.98 | 0 | 1 |
| 17 | 397 | 1 | 2 | 2 | 620 | 2.88 | 0 | 1 |
| 18 | 407 | 1 | 2 | 2.02 | 620 | 3 | 0 | 1 |
| 19 | 387 | 1 | 2 | 1.95 | 620 | 2.76 | 0 | 1 |
| 20 | 403 | 1 | 2 | 1.99 | 620 | 2.82 | 0 | 1 |
| 21 | 425 | 1 | 2 | 2.01 | 620 | 2.07 | 0 | 1 |

On the right side of the table, there are buttons for 'Graph' and 'Raw data', both of which are highlighted with a red box.


5) Auto customizing

AD tool has the auto speed feature against torque setting not to provide any over torque by speed shock. The auto speed is safe speed on the hard joint condition. On the real application, the settings can be changed manually. Auto customizing feature provides most optimized parameter settings for saving cycle time on the real application.





Speed Torque



Click Auto Customizing menu to open the menu.





Auto Customizing

| Customizing control | Preset control | Analyze result |
|---|--|---|
|  Stop | Preset: <input type="text" value="1"/> | A1: <input type="text" value="5863"/> |
|  Soft Joint | <input type="checkbox"/> Editable | A2: <input type="text" value="24"/> |
|  Hard Joint | Torque (Max Trq): <input type="text" value="5 Kgf.cm"/> | Speed: <input type="text" value="1302 rpm"/> |
| | Speed: <input type="text" value="1184 rpm"/> | Free Speed: <input type="text" value="1900 rpm"/> |
| | Free Speed: <input type="text" value="0 rpm"/> | Free Angle: <input type="text" value="4689 °"/> |
| | Free Angle: <input type="text" value="0 °"/> | Seating Point: <input type="text" value="85 %"/> |
| | Seating Point: <input type="text" value="85 %"/> | |
|  Apply | Type: <input type="text" value="TC/AM"/> | |
| | Torque Limit (Min Trq): <input type="text" value="0 %"/> | |
| | Torque Comp.: <input type="text" value="100 %"/> | |
| | Angle: <input type="text" value="0 °"/> | |
| | Min Angle: <input type="text" value="0 °"/> | |
| | Max Angle: <input type="text" value="0 °"/> | |
| | Snug Torque: <input type="text" value="0 Kgf.cm"/> | |
| | Soft Start: <input type="text" value="0 ms"/> | |
| | Torque Rising Time: <input type="text" value="50 ms"/> | |
| | Torque Holding Time: <input type="text" value="2 ms"/> | |

- ① Select Preset # to modify parameter settings
- ② Select one of Soft & Hard joint condition when it is obviously clear or both together when it is not clear to be clarified, then click START
- ③ Apply screw tightening several times until there is no more parameter changing on the simulation & modification window. Be sure that the fastening condition should be same during the process. The system changes parameter values by the previous fastening data.
- ④ Once there is no more changes on the simulation & modification window, click STOP to finish testing.
- ⑤ Click APPLY to apply the settings on the simulation & modification window. The setting can be modified by manually before applying them.

6) Error history display

The latest 8 tool error (system error only) histories which are saved in the controller



ATTENTION : communication is disconnected




ATTENTION : communication is disconnected

ATTENTION : communication is disconnected

Log history is information about the communication of PC to the tool.

7) AD Synchronizing

Two or more spindles up to maximum 31 spindles can be operated with a torque synchronized condition. The spindle drives should be linked by I/O to be synchronized. One drive should be Master and the others should be slaves. To monitor the torque curve of the multi spindles on the separate software- AD Synch, each drive should be connected to the PC by RS422 communication port. The torque curve of maximum 4 spindles can be monitored on a screen with different colors together. But total 31 spindles can be operated in synchronized condition.




[Setting & Wiring]

| Controller Setting 2 | | |
|---------------------------------------|-------------------------------|---|
| A304 - Synchronization | <input type="radio"/> Disable | <input checked="" type="radio"/> Enable |
| A305 - Sync Master | <input type="radio"/> Disable | <input checked="" type="radio"/> Enable |
| ▸ A306 - Wating before sync step (ms) | | |
| ▸ A307 - Wating to sync step (ms) | | |

Parameter setting

- ① A304 Synchronization : Enable
- ② A305 Synch Master : The only 1st spindle should be Master
- ③ A306 Waiting before sync step (ms) : Torque synchronization process starts from the torque seating point. The time to reach to the seating point. Once all spindle reach to the seating point, then move to the next step together.
- ④ A307 Waiting to sync step (ms) : There are 10 sync steps up to the target torque. The waiting time limit between sync steps before moving to next step together.



3. Error & System alarm code

3.1 System error (Er- xxx)

| Code Er- | Error | Description | How to reset |
|-------------|-------------------------------|--|------------------|
| 110 | AD offset error | When the power of controller is ON, the current offset is out of range. Reset and retry booting. If failed, repair is required | RESET button |
| 113 | Spindle parameter read error | Reading failure of spindle parameter | Power Off →On |
| 114 | Screwdriver recognition error | Controller can not recognize the connected screwdriver | Power Off →On |
| 115 | Controller recognition error | Program itself can not recognize the controller information. | Power Off →On |
| 116 | Out of torque range | Torque setting is out of the torque capacity | RESET button |
| 118 | No motor rotation error | When motor rotation is not monitored | RESET button |
| 200 | Parameter reading failure | It failed to read parameter at all. Check the EEP-ROM damage or communication failure | Power Off →On |
| 201 | Parameter Checksum error | The read parameter is wrong by the checksum routine | Power Off →On |
| 220 | Multi-sequence program error | Multi-sequence program is wrong | RESET button |

3.2 Fastening error by the pattern setting (Er- xxx)

| Code Er- | Error | Description | How to reset |
|----------|----------------------------------|---|---|
| 300 | Fastening time limit | Over the fastening time limit on P60 | Auto reset after set time |
| 301 | Loosening time limit | Over the loosening time limit on P61 | Auto reset after set time |
| 302 | Model setting error | Failure in Model programing. | |
| 303 | Model cancel | The Model process is canceled | |
| 304 | Motor stall by loosening failure | Motor stall by loosening failure within time limit on A272 | Auto reset after set time |
| 309 | Bit socket tray | Bit socket tray application error | |
| 310 | Time over in screw counting | Over the time limit of screw counting on A243 | Auto reset after set time |
| 311 | Screw missing | When the work-piece moves out of the working area without complete number of fastening, it provide alarm for set time(A277) and display the latest number. It can be clear to "0" by pressing RESET button. | Auto reset after set time or RESET button |
| 330 | Min Angle error | Target torque reached before the Min angle | Auto reset after set time |
| 331 | Target angle setting errir | Target angle setting is out of the range [AC/TM mode] | Auto reset after set time |
| 332 | Angle over | Target torque reached over the Max angle | Auto reset after set time |
| 333 | No torque complete | Operation stops before complete cycle of torque up by releasing lever trigger | Auto reset after set time |

| | | | |
|-----|--------------------------------|--|---------------------------|
| 334 | Engaging torque detection fail | The engaging torque is not detected in time or angle limit | Auto reset after set time |
| 335 | Converted torque error | Converted torque is out of OK range | Auto reset after set time |
| 336 | Over torque error | torque reached to the high limit of torque | Auto reset after set time |
| 337 | Sync step error1 | Synchronizing time limit over before the seating point | Auto reset after set time |
| 338 | Sync step error2 | Synchronizing time limit over after the seating point | Auto reset after set time |

3.3 System alarm (AL- xx)

| Code AL- | Alarm | Description | How to fix |
|----------------|-----------------------------------|--|---|
| 10 | Over current in Hardware | 1) Motor or encoder cable error 2) Motor coil damage 3) Motor stall by mechanic issue 4) Control error by EMC | 1) Cable check and repair or replace 2) Resistance test between UVW phase 3) Remove the filaure 4) Check FG connection and improve condition |
| 14 | Over current in Software | | |
| 16 | Current limit over | | |
| 11 22 23 | Overload by temperature | 1) Environment over 50°C 2) Continuous overload 3) Motor cable open | 1) Check room temperature 2) Change to higher capacity one 3) Check cable |
| 21 | Continuous overload | 1) Overload application 2) Motor or encoder cable error | 1) Change to higher capacity one 2) Check cable |
| 22 25 | Over temperature in drive | 1) Environment over 50°C 2) Others | If room temperature is normal, replace drive |
| 24 | Motor cable open | Motor cable open or short circuit of motor windings | Replace cable or motor |
| 30 | Encoder communication error | 1) Encoder cable error 2) Drive error | 1) Replace encoder cable 2) Replace drive |
| 31 | Encoder cable open | | |
| 32 34 | Encoder data error | | |
| 38 | Wrong recognition | 1) Spindle and drive can not be matched as a pair 2) Encoder or encoder cable error | 1) Check the model of spindle and drive 2) Replace encoder cable |
| 40 | Under voltage | 1) Input voltage is lower than rated input voltage 2) Voltage drop down during running | 1) Main power should be over 190VAC 2) Use 3 phase input power |
| 41 | Over voltage | 1) Input voltage is over than rated input voltage 2) Acceleration/deceleration error | 1) Check power input 2) Have longer acc/dcc time setting |
| 42 | Main power fail | Power input voltage out of the range 200 – 230VAC | Check the power voltage input |
| 43 | Control power fail | | |
| 50 | Over speed limit | 1) Motor or encoder cable error 2) Encoder failure 3) Drive failure | Repair or replace the failure |
| 60 | USB com port | | Contact to the manufacturer |
| 63 | Parameter checksum | | |
| 64 | Parameter range | | |
| 70 | Drive & spindle combination issue | | |
| 71 | Factory setting required | | |

Mountz Calibration & Repair Services

Mountz Inc. features an experienced calibration and repair staff. Our trained technicians can calibrate and repair most any tool. Mountz provides rapid service with quality that you can trust as we offer three state-of-the-art calibration lab and repair facilities that can calibrate up to 20,000 lbf.ft.

Since 1965, Mountz Inc. has proven in-depth knowledge of torque is reflected in our tool's craftsmanship and our ability to provide solutions to both common and uncommon torque applications. We perform calibrations in accordance with ANSI/NCSL-Z540. Mountz is dedicated solely to the manufacturing, marketing and servicing of high quality torque tools.

Tool Service & Repair Capability

- Torque Wrench Calibration: Click Wrench, Dial Torque Wrench, Beam Wrench, Cam-Over & Break-Over Wrench
 - Torque Screwdrivers: Dial, Micrometer, Preset & Adjustable
 - Torque Analyzers/Sensors: All brands
 - Electric Screwdrivers: All brands
 - Air Tools: All brands
- Impact Wrenches, Drills, Pulse Tools, Grinders, Percussive Tools, Air Screwdrivers, Nutrunners, DC Controlled Nutrunners
- Torque Multipliers: All brands

Mountz Service Locations

Eastern Service Center

19051 Underwood Rd.
Foley, AL 36535
Phone: (251) 943-4125
Fax: (251) 943-4979

Western Service Center

1080 N.11th Street
San Jose, CA 95112
Phone: (408) 292-2214
Fax: (408) 292-2733

www.mountztorque.com
sales@mountztorque.com



Twitter: @mountztorque

Download a "Service Form" and include a copy when you send the tools in to be serviced.

Looking for fasteners?
www.mrmetric.com

