
DPC Touch V2 / New Features Added







Same housing, Improved components





I/O port DB44 Encoders RS232

©2019 Mountz, Inc. All rights reserved.

Mountz Confidential



Implementation of Modbus TCP/IP (Ethernet)





Implementation of Modbus TCP/IP (Ethernet)

Accessible information(Live):

- All the parameters in the setting menu
- Job#, step#, screw#, etc...
- Encoders position
- Tool info (F/R, lock, motor run, torque up...)

Accessible information (Per event):


- Event # + timestamp
- Event type
- Job#, step#, screw#, etc...
- Encoders position when fastening was performed
- Barcodes

Actions:

- Job selection
- Reset Job / Step
- Skip / Back
- Init (code 77)




Integrated images in fastening steps (set up)







Integrated images in fastening steps (operation)





New interface








Charger

Mountz Confidential




New interface














New interface








New interface







Logs available



- One folder per year
 - One sub folder per month
 - One .csv file per day

No	Time	Job no	Step no	Step type	Action type	Action result	Error	Job Total screw	Job Remain screw	Step Total screw	Step Remain screw	Preset	Barcode
4	12:33:22	1	1	None	Job Select	0	0	8	8	0	0	0	
5	12:33:22	1	2	Fastening	Step Select	5	0	8	8	5	5	0	
6	12:33:26	1	2	Fastening	Fasten	1	0	8	7	5	4	1	
7	12:33:27	1	2	Fastening	Fasten	1	0	8	6	5	3	2	
8	12:33:29	1	2	Fastening	Fasten	1	0	8	5	5	2	3	
9	12:33:31	1	2	Fastening	Fasten	1	0	8	4	5	1	4	
10	12:33:39	1	2	Fastening	Fasten	1	0	8	3	5	0	5	
11	12:33:39	1	3	Fastening	Step Select	3	0	8	3	3	3	0	
12	12:33:46	1	3	Fastening	Fasten	1	0	8	2	3	2	8	
13	12:33:48	1	3	Fastening	Fasten	1	0	8	1	3	1	12	
14	12:33:49	1	3	Fastening	Fasten	1	0	8	0	3	0	15	
15	12:33:49	1	4	Delay	Step Select	3000	0	8	0	0	0	0	
16	12:33:52	1	4	Delay	Job End	1	0	8	0	0	0	0	




Rest position

- Set position in the settings
- Assign the rest position to anoutput
- > Encoders turn blue and output is activated when rest position is reached
- v Designed to make sure the tool is not interfering when the product is moving along the production line
- Automatic restart of the job
 - Activated or not
 - ➤ If not activated, the next job needs to be selected manually, via I/O or barcode scanning



Blinking outputs



New confirmation funtions in the delay step






Barcode can be manually typed





Encoders colors:



Compatibility V1 / V2





Mountz Confidential

DPC Touch V2



THANK YOU!

www.mountztorque.com