

Software and USB drivers for Scout II Screw Presenters

Installation Recommendations:

- Create a new folder in the root of your C drive, label as "[Scout II](#)"
- Download and save the following zipped files to the newly created folder
 - "[Scout_II_V1.3.zip](#)"
 - "[CP210x_VCP_Win_XP_S2K3_Vista_Win7.zip](#)"
- Go to folder "[Scout II](#)"
- Locate and extract the zipped file "[Scout_II_V1.3.zip](#)" to the newly created folder "[Scout II](#)"
- Go to folder "[Scout II](#)", right click "[Scout_II_V1.3.exe](#)", Send To > Desktop (create shortcut)

Installation of USB Drivers:

- Go to folder "[Scout II](#)"
- Run the "[CP210x_VCP_Win_XP_S2K3_Vista_Win7.exe](#)" to install the USB drivers. Follow the prompts to complete the installation. Please note you may be prompted to restart your system.

Misc Notes:

Administrative privileges are required to perform USB driver installation

Mountz, Inc., 1080 N. 11th Street, San Jose, CA 95112 United States

Phone: 408.292.2214 Fax: 408.292.2733 Website: <http://www.mountztorque.com>