

# Multiplexer

for PTT and LTT



**MULTIPLEXER**

Item #072998  
 Size (W x L x H): 6 3/4" x 6 3/4" x 1 3/8"  
 Weight: 1.3 lbs.

**KEY FEATURES**

Connects 1-4 transducers to the Torque Analyzer and switches between the transducers manually or automatically.

Eliminates the need to plug and unplug transducers.

When the PTT or LTT is connected to the Multiplexer it reviews the Multiplexer (Mux) to determine what transducers are connected and downloads the identity and calibration data for each of the attached transducers.

# Bar Code Reader

for PTT and LTT



**BAR CODE READER** Item #072997

**KEY FEATURES**

Designed to scan Bar Codes on tools and start Tool Tests automatically.

Reduces operational time for users with a large number of Tool Tests stored in the analyzer.

The PTT or LTT are designed to work with this bar code reader.

## Operating Multiplexer and Bar Code Reader with PTT or LTT

This combination provides a flexible, time saving solution that reduces the potential for operator error. For users that have many Tool Tests and using multiple torque transducers, these two accessories are the ideal solution for torque testing.

