


MR3, MR-6 & MR-11 Parts Lists

Version 1.1



No.	Part Number	Description	Qty.
1	Case	18-R610001	1
2	Handle (A)	18-H9610012	1
3	Handle (B)	18-H9610013	1
4	Collar	18-H9610014	1
5	Spring	18-H9610015	1
6	Screw	18-SC614	1
7	Spindle	18-R61006	1
8	Hanger	18-H9610005	1
9	Drum	18-R610003	1
10	Spiral Spring for MR-3	18-R610004	1
	Spiral Spring for MR-6	18-R610304	1
	Spiral Spring for MR-11	18-R610504	1
11	Drum Cover	18-R610008	1
12	Screw	18-SC2.614	3
13	Wire Rope	18-R610009	1
14	Lock (A)		1
15	Lock (B)		2
16	Thimble		1
17	Spring Hook		1
18	Shock Absorber	18-R610010	1
19	Cover	18-R610002	1
20	Screw	18-SC2.614	3
21	Stop Ring	18-STW13	1
22	Bushing	18-R910016	1
23	Name Plate	18-R610011	1
		18-R610311	1
		18-R610511	1
24	Stopper Set	18-R610017	1
25	Box		1