


STB 35 Parts List



No.	Part Number	Description	Qty.
1.	20-B34220	Handle Sub-Assembly Blue Polyshrink	1
2.	20-A32800	Roller	1
3.	20-A60020	Roller Thrust Pad	2
4.	20-A60320	Main Spring	1
5.	20-A18550	Adjusting Screw Sub Assembly	1
6.	20-A19010	Hand Grip	1
7.	20-A20252	End Cap - Blue	1
8.	20-A73201	Thrust Bearing	1
9.	20-B86060	Cam - 5 Lobe RH	1
10.	20-B30200	STB 35 Spindle - Sq. Dr. RH	1
11.	20-P31380	O-Ring	1
12.	20-A12060	Pawl	2
13.	20-A59850	Pawl Spring	2
14.	20-A11160	Snap Ring	1
15.	20-P10130	'O' Ring	1
16.	20-A60000	Bush (Front)	1
17.	20-P19060	O Ring	1
18.	20-A11120	Seal Spacer	1
19.	20-P10090	Retaining Ring RR86-TSN125	1
20.	20-B29520	Carrier Arm - 16mm Spigot	1
21.	20-A30260	Top Cover Locating Bush STB35	2
22.	20-A60120	Spring Cup	1
23.	20-P11040	Spring	1
24.	20-A60110	Locating Pin	1
25.	20-A30270	Securing Bolt	1
26.	20-A30210	Return Spring - STB35	1
27.	20-B29830	Top Cover - Machined	1
28.	20-P24350	Skt Cap Screws	2



Version 1.1