


# STB 70 Parts List



No.	Part Number	Description	Qty.
1	20-A73202	Thurst Bearing	1
2	20-C35060	Spindle - STB70	1
3	20-A35130	16mm Carrier Sub-Assy-STB70	1
4	20-B34450	STB70 Top Cover - Machined	1
5	20-A59780	Seal Cover	1
6	20-A59700	Bush (Front)	1
7	20-C86070	Cam - 5 Lobe, TSN55	1
8	20-A32790	Roller	1
9	20-A59720	Roller Thrust Pad - TSN55	1
10	20-A60310	Main Spring	1
11	20-A59730	Spacer End Spigot	1
12	20-B59790	Spacer Tube	1
13	20-A59800	End Pad	1
14	20-A18600	Adjusting Screw - Sub-Assy	1
15	20-A50393	End Cap - Gloss Blue	1
16	20-A74741	Hand Grip	1
17	20-A12080	Pawl	2
18	20-A59850	Pawl Spring	4
19	20-P10140	Spritol Ring	1
20	20-P10120	O'-Ring	1
21	20-P31950	O'-Ring	1
22	20-P24350	SKT Cap Screw M2.5 x 10	2
23	20-A30260	Top Cover Locating Bush -STB35	2
24	20-A30270	Securing Bolt	1
25	20-P10130	O'-Ring	1
26	20-A35080	Return Spring - STB70	1
27	20-A30690	Tool Label - STB Head	1
28	20-A30701	Tool Label - STB70 Handle	1
29	20-B35090	Handle/Head Sub-Assy - STB70	1
30	20-B34470	STB70 Carrier - 9x12 Cavity (Machined)	1



Version 1.1