


BFA120 ESD Robotic Screwdriver Parts List

December 30, 2021





BFA120 ESD Robotic Screwdriver Parts List

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-PSW2207	SCREW	3	24	14-PFE1302	SHAFT [LEVER]	1
2	14-532-0002	FLANGE	1	25	14-PAL1932	BALL	2
3	14-PFE1801	ADJUSTER	1	26	14-PFE1910	PIN [ROLLER]	2
4	14-PFE1132	HOLDER ASSY [TORQUE SPRING]	1	27	14-PFE1106	CLUTCH ASSY [B]	1
5	14-PFE1816	SPRING [TORQUE]	1	28	14-PFFZ511A	SENSOR ASSY [LEVER]	1
6	14-PSW2216	WRENCH BOLT	4	29	14-PSW2211	SCREW	2
7	14-501-0004	ADAPTOR	1	30	14-PSW2207	SCREW	6
8	14-PSW2201	WRENCH BOLT	3	31	14-PFE1201A	GEAR [CASE]	1
9	14-PFE1131	COVER ASSY [TOP]	1	32	14-PFE1212	GEAR [2ND IDLE B]	4
10	14-PFE1973	C-RING [BIT SOCKET]	1	33	14-PFE1915	PIN [CENTER]	1
11	14-PFE1410	COLLAR [BIT]	1	35	14-PFE1103	HOLDER ASSY [GEAR]	1
12	14-PFE1964	SPRING [COLLAR]	1	36	14-PFE1217	GEAR [1ST IDLE B]	3
13	14-PFE1955	C-RING	1	37	14-590-0048	WASHER	1
14	14-3000030	SLEEVE ASSY	1	38	14-PFE1903	SNAP RING	1
15	14-PAL1927	BALL	2	39	14-901-0087	GEAR BOX	1
16	14-PFE1412	BIT SOCKET [A]	1	40	14-PFE1236	GEAR [PINION B]	1
17	14-PFE1920	BEARING [THRUST]	1	41	14-PFF4005A	MOTOR ASSY [SET]	1
18	14-557-0022	PIN [HOLDER]	1	42	14-574-0001	SHELL	1
19	14-PFE1907	BEARING [BALL]	1	43	14-PSW2202	SCREW	2
20	14-PFE1327	PIN [NEEDLE]	3	44	14-PSW2207	SCREW	2
21	14-PFE1118	BEARING COVER ASSY [LEVER]	1	45		HOUSING SET	1
22	14-PFE1908	BEARING [BALL]	1	46	14-PSW2602	SCREW	4
23	14-PFE1319	RING [SLIDE]	1				



BFA120 ESD Robotic Screwdriver Parts List

No.	Part Number	Description	Qty.
47	14-PFF1130	COVER ASSY [SWITCH]	1
48	14-PFF1842A	SUPPORTER [PCB]	2
49	14-PFF1824A	NUT	1
50	14-PFF1719	COVER [CONNECTOR LOCK]	1
51	14-PSW2207	SCREW	1
52	14-5000070	CAP	2
53	14-590-0023	WASHER	1
54	14-PFF1824	NUT	1
55	14-332-0023	CONTROL PCB ASSY [SET]	1
56	14-331-0008	AMP PCB ASSY [SET]	1
57	14-334-0013	PCB ASSY	1
58	14-548-0117	LABEL [WINDOW]	1
59	14-PELZ932A	Cable 6Pin (3M, Standard)	1

