


YF100N-A Electric Screwdriver Parts List

March 17, 2022





YF100N-A Electric Screwdriver Parts List

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-5000905	ADJUSTER	1	24	14-557-0027	PIN [NEEDLE]	4
2	14-5000899	PIN [ADJUST]	4	25	14-3000492	BEARING COVER ASSY [LEVER]	1
3	14-5001020	SPRING [TORQUE]	1	26	14-582-0002	SUPPORTER [BEARING]	1
4	14-5000069	WRENCH BOLT	4	27	14-509-0002	BEARING [BALL]	1
5	14-3000991	COVER ASSY [TOP]	1	28	14-573-0011	SHAFT [A, LEVER]	1
6	14-5000945	SNAP RING	1	29	14-569-0015	RING [SLIDE]	1
7	14-5000914	SUPPORTER [COLLAR SPRING]	1	30	14-573-0021	SHAFT [B, LEVER]	1
8	14-5000903	SPRING [COLLAR]	1	31	14-507-0011	BALL	3
9	14-5000912	COLLAR [A]	1	32	14-5000816	CLUTCH	1
10	14-5000904	C-RING [STOP]	1	33	14-509-0016	BEARING [BALL]	1
11	14-5000616	SUPPORTER [SLEEVE]	1	34	14-536-0055	GEAR [CASE]	1
12	14-5000909	BIT SOCKET [A]	1	35	14-PSW2309	WRENCH BOLT	2
13	14-500950	BALL	2	36	14-5000665	SCREW [FL TORX]	3
14	14-PAL1231	PIN [GEAR HOLDER]	1	37	14-3000496	HOLDER ASSY [GEAR]	3
15	14-SK1954	C-RING	1	38	14-536-0010	GEAR [IDLE]	9
16	14-557-0020	PIN [HOLDER]	1	39	14-557-0027	PIN [NEEDLE]	1
17	14-PSK1921	BEARING [THRUST]	1	40	14-536-0091	GEAR [PINION]	2
18	14-580-0013	SPACER [BEARING]	1	41	14-590-0015	WASHER	1
19	14-509-0001	BEARING [BALL]	3	42	14-579-0010	SNAP RING	1
20	14-5000064	SPRING [LIMIT]	1	43	14-536-0084	GEAR [MOTOR PINION]	1
21	14-3000076	SLIDE BAR ASSY	1	44	14-5000789	WRENCH BOLT	3
22	14-PSW2211	SCREW	2				
23	14-3000528	SENSOR ASSY [LEVER]	1				

Silicon Valley Corporate Headquarters: 1080 North 11th Street, San Jose, CA 95112 Phone: (408) 292-2214 Fax: (408) 292-2733

www.mountztorque.com



YF100N-A Electric Screwdriver Parts List

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
45	14-321-0003	FLANGE ASSY [MOUNTING]	1	63	14-582-0036	SUPPORTER [TORQUE SPRING WASHER]	1
46	14-330-0048	MOTOR ASSY [SET]	1	64	14-509-0021	BEARING [BALL]	1
47	14-5000529	BLDC MOTOR	1	65	14-580-0006	SPACER [6701, BEARING]	1
48	14-334-0070	PCB ASSY	1	66	14-582-0038	SUPPORTER [TORQUE SPRING]	1
49	14-515-0005	WRENCH BOLT	2	67	14-544-0028	HOUSING NUT	1
50	14-3000916	HOUSING [UPPER]	1		14-3000500	Power Tool Cable for YF-Series	1
51	14-PKK1911	KEY	1				
52	14-329-0016	LEVER ASSY	1				
53	14-PSK1327	PIN [NEEDLE]	1				
54	14-581-0037	SPRING [LEVER]	1				
56	14-PSW2602	SCREW	6				
57	14-PFF1130	COVER ASSY [SWITCH]	1				
58	14-313-0005	CONNECTOR ASSY	1				
59	14-541-0001	HOOK	1				
60	14-571-0030	SCREW	1				
61	14-PSW2201	WRENCH BOLT	3				
62	14-548-0033	LABEL [MAIN, FRONT]	1				