


E250-A Lever Start Model (110V)

December 10, 2022





E250-A Lever Start Model (110V)

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-500205	Adjuster	1	31	14-PSS1206	Clutch	1
2	14-508130	Torque Spring Holder Assy	1	32	14-PSM1906	Ball Bearing	1
3	14-PSW2201	Wrench Bolt M2.5x5L	3	33	14-PSW2202	Screw (M Philips M2.6x5L)	2
4	14-PSS1131	Top Cover Assy	1	34	14-PSM1201	Gear Case	1
5	14-520230	Torque Spring - Silver	1	35	14-PSW2310	Screw (M Philips M3x6L Washer)	1
	14-520235	Torque Spring - Bronze	1	36	14-QSM0323	Earth Wire	1
	14-520210	Torque Spring - Black	1	37	14-PSS1110	Gear Holder Assy	1
6	14-500111	Bit Socket Ring	1	38	14-PSS1212	2nd Idle Gear	3
7	14-520011	Bit Collar	1	39	14-PSS1103	1st Gear Holder Assy	1
8	14-520621	Collar Spring	1	40	14-PSS1217	1st Idle Gear	3
9	14-PSK1954	C-Ring	1	41	14-PAL1901	Snap Ring (R22)	1
10	14-3000122	Sleeve Assy	1	42	14-PSS1136	Fan Gear Assy	1
11	14-PSK1327	Needle Pin	3	43	14-501803	Motor Assembly 110V	1
12	14-PAL1928	Steel Ball (for 1/4 F/Hex Dr Models)	2	44	14-501831	Brush Cap	2
13	14-PSK1401	Bit Socket A	1	45	14-PSM4100	Carbon Brush Assy	2
14	14-PAL1231	Gear Holder Pin	1	46	14-502505	Control PCB Assembly (110V)	1
15	14-PAL1946	Bend Washer	1	51	14-520480	Screw (M3X6L)	2
16	14-PSK1347	Spacer	1	52	14-PSM1827	Upper Housing	1
17	14-PSK1921	Thrust Bearing	1	53	14-502302	Screw (Torx 3x12 L)	3
18	14-PSW2901	Screw, (M Slot M2.3x10L)	2	54	14-500680	Hook	1
19	14-PSS1118	Bearing Cover Assy	1	55	14-PSW2601	Screw (T Philips 2x16L)	2
20	14-PSS1319	Slide Ring	1	56	14-PSW2801	Washer (Spring M2.3)	2
21	14-PSS1302	Shaft	1	57	14-PELS301	Micro Switch	1
22	14-PAL1932	Steel Ball 4mm	2	58	14-PAL1130	Switch Cover Assy	1
				59	14-PELS102	Slide Switch Assy	1



E250-A Lever Start Model (110V)

No.	Part Number	Description	Qty.
61	14-PSS1802	Housing Nut	1
62	14-PSM1828	Lower Housing	1
63	14-PSM1841	Lever Spring	1
64	14-PSK1327	Needle Pin	1
65	14-PSM1835A	Lever	1
66	14-QSM0902	Sleeve	1
67	14-PSS3010	Power Cord 110V	1