


BF035 ESD Model (4mm HIOS)

Rev 2.6 5/7/2014



BF035 ESD Model (4mm HIOS)

Rev 2.6 5/7/2014

No.	Part Number	Description	Qty.	Note
1	14-5000086	Adjuster	1	
2	14-5000089	Lock Nut	1	
3	14-3000193	Torque Spring Holder Assy	1	
4	14-5000113	Torque Spring (Bronze)	1	
	14-5000114	Torque Spring (Silver)	1	
5	14-5000130	Torque Spring Support	1	
6	14-PSW2602	Screw	7	
7	14-3000194	Top Cover Assy (Mini)	1	
8	14-5000038	Bit Socket Ring	1	
9	14-5000040	Collar	1	
10	14-5000039	Collar Spring	1	
11	14-5000041	Collar Spring Support	1	
12	14-3000740	Clutch Supporter Assy	1	
16	14-PAL1927	Steel Ball	2	
17	14-PAL1929	Steel Ball	2	
18	14-3000182	Bit Socket Assy	1	
19	14-5000171	Steel Ball	2	
20	14-5000103	Clutch 1H	1	
21	14-PFE1920	Thrust Bearing	1	
22	14-PFE1907	Ball Bearing	2	
23	14-3000183	Gear Case Assy	1	
24	14-5000195	Screw	1	
25	14-3000184	Sensor PCB Assy	1	
26	14-PSW2205	Screw	2	
27	14-3000185	BF035 Shaft Assy	1	
28	14-5000119	Ring Gear	1	
29	14-5000116	Idle Gear	3	
30	14-PFE1915	Center Pin	1	
31	14-3000187	Gear Holder Assy (BF035)	1	
32	14-5000116	Idle Gear	3	

No.	Part Number	Description	Qty.	Note
33	14-5000118	Pinion Gear	1	
34	14-3000195	Motor Assy (Mini BF)	1	
35	14-3000926	Housing Set (Mini BF Series)	1	
37	14-5000088	Housing Nut (Mini BF)	1	
38	14-3000197	Lever Assy (Mini BF)	1	
39	14-5000123	Lever Spring	1	
40	14-PFE1807	Spring Holder Pin	1	
41	14-3000483	Switch Cover Assy	1	
42	14-PAL1803	Hook	1	
43	14-PSW2601	Screw	2	
44	14-3000198	Control PCB Set (BF035)	1	
45	14-5000125	PCB Supporter	2	
46	14-3000479	AMP PCB Set (Mini BF)	1	
47	14-3000203	Motor & Amp & 6Pin Connector N	1	
48	14-PELZ932A	Cable 6Pin (3M, Standard)	1	