


CL825AXH Parts List

Rev 1 (3/27/12)



CL825AXH Parts List

No.	Part Number	Description	Qty.
1	Torque Adjusting Nut	41-CLF65-0010	1
2	Fixing Screw	41-CL9-0020	1
3	Flange	41-CL816-0040	1
4	Spring Holder A	41-CLF7-0030	1
5	Torque Adjusting Spring (Purple)	41-CLF7-0050	1
6	Clutch Cover	41-CL816-0060	1
	Transmission Assy 8-33 (W/O 10,23,32)	41-CL825-TM	1
7	Set Screw 3x5.5	41-STB30X055	2
8	Torque Adjusting Bolt Set Screw	41-STP26X080	2
9	Torque Adjusting Bolt	41-CL816-0100	1
10	Limit Switch Prop Spring	41-CL816-0110	1
11	Clutch Supporter	41-CL816-0120	1
	Joint Shaft Assembly 12 - 16	41-CL816-JS	1
12	Collar Stopper	41-CL65-0110	1
13	Joint Shaft Collar	41-CLF65XN-0140	1
14	Collar Spring	41-CL65-0130	1
15	Joint Shaft	41-CL816-0160	1
16	Steel Ball 2.0mm	41-BALL-02	3
17	Joint Shaft Lock Pin 2.5x11.8	41-CL816-0180	1
18	Set Screw 3x3	41-SH30X030	1
19	Set Screw 3x3	41-SH30X030	1
	Gear Assembly 20 - 33 (W/O 23,32)	41-CL825-GR	1
20	Thrust Bearing	41-CL816-0200	1
21	Gear Case	41-CL816-0210	1
22	Steel Ball 6.35mm	41-BALL-0635	1
23	Set Screw 4x10	41-SC40X100	4
24	Cam Roller 5x7	41-CL65-0230	1
25	Internal Gear	41-F9-0220	1
26	Thrust Bearing	41-F9-0170	1
27	Lower Planet Cage	41-CL816-0280	1
28	Planet Gear A	41-CL825-0290	1
29	Center Pin	41-F9-0260	1
30	Upper Planet Cage	41-F98-0270	1
31	Planet Gear Bfor CL-825A	41-CL816-0320	1
32	Grease Seal	41-F9-0270	1
33	Limit Switch	41-CL4-0230	1
34	Pinion Gear	41-CL816-0350	1
35	Motor	41-CL816-0391	1
36	Carbon Brush Cap	41-CL816-0480	1
38	Noise Filter B	41-ACL10-0600	1
39	XH Seal	41-CLF4XH-0550	1
40	Set Screw 3x8	41-SPF30X080	4
41	Switch Cover	41-CL816-0451	1
42	Mark Label	41-CL825-0440	1
43	5-Pin Connector (SCK1605R)	41-CL816-0470	1
44	Set Screw 3x8 Bo	41-STPB30X080	1
45	5-Core Cord 4-5P 3M	41-CL816XH-3450	1