


HF100N-A ESD Electric Driver (1/4 F/Hex)

Rev 2.0 5/19/17





HF100N-A ESD Electric Driver (1/4 F/Hex)

Rev 2.0 5/19/17

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-5000905	ADJUSTER	1	39	14-5000333	IDLE GEAR	9
2	14-5000899	ADJUST PIN	1	40	14-5000622	NEEDLE PIN	1
3	14-5001019	TORQUE SPRING	1	41	14-5000336	PINION GEAR	2
4	14-5000069	WRENCH BOLT	4	42	14-5000345	WASHER	1
5	14-3000991	TOP COVER ASSY	1	43	14-5000374	SNAP RING	1
6	14-5000945	SNAP RING	1	44	14-5000530	WRENCH BOLT	4
7	14-5000914	COLLAR SPRING SUPPORT	1	45	14-5000614	MOUNTING FLANGE	1
8	14-5000903	COLLAR SPRING	1	46	14-5000339	MOTOR PINION GEAR	1
9	14-5000912	COLLAR A	1	47	14-5000605	BLDC MOTOR	1
10	14-5000904	SLEEVE	1	50	14-PSW2201	WRENCH BOLT	3
11	14-5000616	SLEEVE SUPPORT	1	51	14-5000322	HF HOUSING NUT	1
12	14-5000909	BIT SOCKET A	1	52	14-5000476	WRENCH BOLT	2
13	14-PAL1929	STEEL BALL	2	53	14-3000915	HF HOUSING SET	1
14	14-PAL1231	GEAR HOLDER PIN	1	54	14-PKK1911	KEY	1
15	14-PSK1954	C-RING	1	55	14-3000160	LEVER ASSY	1
16	14-5000274	HOLDER PIN	1	56	14-PSK1327	NEEDLE PIN	1
17	14-PSK1921	THRUST BEARING	1	57	14-PFE1841	LEVER SPRING	1
18	14-5000457	BEARING SPACER	1	59	14-PSW2602	SCREW	4
19	14-5000376	BALL BEARING	3	60	14-PFF1130	SWITCH COVER ASSY	1
20	14-5000064	LIMIT SPRING	1	61	14-5000630	HOOK	1
21	14-3000076	SLIDE BAR ASSY	1	62	14-5000595	BUTTON CAP	2
22	14-PSW2211	SCREW	2	63	14-3000767	CONTROL PCB SET (LEVER)	1
23	14-3000528	SENSOR ASSY (LEVER)	1	64	14-PFF1824	NUT	2
24	14-5000622	NEEDLE PIN	4	65	14-PSW2803	SPRING WASHER	2
25	14-3000492	BEA. COVER ASSY (LEVER)	1	66	14-PFF1842A	PCB SUPPORT	2
26	14-5000297	BEARING SUPPORT	1	67	14-3000768	AMP PCB SET	1
27	14-5000377	BALL BEARING	1	68	14-3000772	MOTOR SET (PUSH)	1
28	14-5000316	LEVER SHAFT A	1	69	14-5000143	THERMO SILICON PAD	1
29	14-5000344	SLIDE RING (YF & HF)	1	70	14-5000786	HEAT SINK	1
30	14-5000618	LEVER SHAFT B	1	71	14-5000701	WINDOW LABEL	1
31	14-5000475	STEEL BALL	3	72	14-5000908	TORQUE SPRING WASHER	1
32	14-5000816	CLUTCH	1	73	14-5001021	BALL BEARING	1
33	14-5000474	BALL BEARING	1	74	14-5000911	6701 BEARING SPACER	1
34	14-5000613	GEAR CASE	1	75	14-5000907	TORQUE SPRING SUPPORT	1
35	14-PSW2309	WRENCH BOLT	2	76	14-PELZ932A	CABLE 6 PIN (3M, STANDARD)	1
36	14-PSW2305	SCREW	1				
37	14-5000665	SCREW	4				
38	14-3000496	GEAR HOLDER ASSY	3				