



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25

26 27 28 x2 29 30 32 33 34 35 36 37 38 39 53 41 43 45 x2 44 46 47 x2 48 x2 49 50 51 52 54

MAGNET DIRECTION

LF120

28 x2 26 x3

48 x2

49

54

50

46

47 x2

41

43

45 x2

44

38

40

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

54

50

46

47 x2

41

43

45 x2

44

46

47 x2

48 x2

49

51

52

53

39

38

37

36

35

34

33

32

30

29

27

26

28 x2

26 x3

25

24

23

22

21

20

19

18

17

16

15

14

13

**mr.
metric®**



LF120P-A ESD Electric Driver (1/4 F/Hex)

Rev 1.0 5/21/13

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-5000495	ADJUSTER	1	36	14-PFE1235	PINION GEAR	1
2	14-3000705	TORQUE SPRING HOLDER ASS'Y	1	37	14-3000702	MOTOR ASSY	1
3	14-5000560	TORQUE SPRING (GOLD)	1	38	14-5000072	SCREW	2
4	14-PSW2204	WRENCH BOLT	4	39	14-5000562	LF UPPER HOUSING	1
5	14-3000704	TOP COVER ASSY	1	40	14-5000563	LF LOWER HOUSING	1
6	14-PAL1973	BIT SOCKET RING	1	41	14-5000565	LF ATTACHMENT	1
7	14-5000063	COLLAR SPRING	1	43	14-PSK1327	NEEDLE PIN	1
8	14-5000060	COLLAR A	1	44	14-3000737	AMP PCB SET	1
9	14-PSK1401	BIT SOCKET A	1	45	14-5000125	PCB SUPPORTER (MINI)	2
10	14-PAL1928	STEEL BALL [2]	2	46	14-3000736	CPU PCB ASSY	1
11	14-PAL1231	GEAR HOLDER PIN	1	47	14-PSW2601	SCREW	2
12	14-PSK1954	C-RING	1	48	14-PSW2602	SCREW	2
13	14-5000498	SLEEVE FOR LF	1	49	14-PFF1130	SWITCH COVER ASSY	1
14	14-PSK1327	NEEDLE PIN	3	50	14-500680	HOOK	1
15	14-3000709	BEA. COVER ASS'Y (PUSH)	1	51	14-PSW2201	WRENCH BOLT	3
16	14-5000064	LIMIT SPRING	1	52	14-5000496	HOUSING NUT FOR LF	1
17	14-3000076	SLIDE BAR ASS'Y	1	53	14-5000715	DRIVER LABEL	1
18	14-3000086	SENSOR ASS'Y (PUSH)	1	54	14-PELZ932A	Cable 6Pin (3M, Standard)	1
19	14-PSW2211	SCREW	2				
20	14-3000088	PUSH SHAFT ASSY	1				
21	14-5000078	PUSH SPRING	1				
22	14-PFF1319	SLIDE RING	1				
23	14-PAL1932	STEEL BALL	2				
24	14-5000079	SHAFT B	1				
25	14-3000268	CLUTCH ASS'Y (LF120)	1				
26	14-5000665	SCREW	4				
27	14-PFE1201A	GEAR CASE	1				
28	14-PSW2201	WRENCH BOLT	2				
29	14-5000067	2ND IDLE GEAR	4				
30	14-PFE1915	CENTER PIN	1				
32	14-PFE1102	1ST GEAR HOLDER ASSY	1				
33	14-5000067	2ND IDLE GEAR	4				
34	14-PFE1947	WASHER	1				
35	14-PFE1903	SNAP RING	1				