


# LF180P-A ESD Electric Driver (1/4 F/Hex)

Rev 1.0 5/21/13



**Contact**

**Mountz Inc.**

Phone: 408.292.2214

Fax: 408.292.2733

sales@mountztorque.com

www.mountztorque.com

Looking for fasteners?

www.mrmetric.com

**mr.  
metric**®



# LF180P-A ESD Electric Driver (1/4 F/Hex)

Rev 1.0 5/21/13

No.	Part Number	Description	Qty.	No.	Part Number	Description	Qty.
1	14-5000495	ADJUSTER	1	36	14-PFE1236	PINION GEAR B	1
2	14-3000705	TORQUE SPRING HOLDER ASS'Y	1	37	14-3000702	MOTOR ASSY	1
3	14-5000549	TORQUE SPRING (SILVER)	1	38	14-5000072	SCREW	2
4	14-PSW2204	WRENCH BOLT	4	39	14-5000562	LF UPPER HOUSING	1
5	14-3000704	TOP COVER ASSY	1	40	14-5000563	LF LOWER HOUSING	1
6	14-PAL1973	BIT SOCKET RING	1	41	14-5000565	LF ATTACHMENT	1
7	14-5000063	COLLAR SPRING	1	43	14-PSK1327	NEEDLE PIN	1
8	14-5000060	COLLAR A	1	44	14-3000737	AMP PCB SET	1
9	14-PSK1401	BIT SOCKET A	1	45	14-5000125	PCB SUPPORTER (MINI)	2
10	14-PAL1928	STEEL BALL [2]	2	46	14-3000736	CPU PCB ASSY	1
11	14-PAL1231	GEAR HOLDER PIN	1	47	14-PSW2601	SCREW	2
12	14-PSK1954	C-RING	1	48	14-PSW2602	SCREW	2
13	14-5000498	SLEEVE FOR LF	1	49	14-PFF1130	SWITCH COVER ASSY	1
14	14-PSK1327	NEEDLE PIN	3	50	14-500680	HOOK	1
15	14-3000709	BEA. COVER ASS'Y (PUSH)	1	51	14-PSW2201	WRENCH BOLT	3
16	14-5000064	LIMIT SPRING	1	52	14-5000496	HOUSING NUT FOR LF	1
17	14-3000076	SLIDE BAR ASS'Y	1	53	14-5000715	DRIVER LABEL	1
18	14-3000086	SENSOR ASS'Y (PUSH)	1	54	14-PELZ932A	Cable 6Pin (3M, Standard)	1
19	14-PSW2211	SCREW	2				
20	14-3000088	PUSH SHAFT ASSY	1				
21	14-5000078	PUSH SPRING	1				
22	14-PFF1319	SLIDE RING	1				
23	14-PAL1932	STEEL BALL	2				
24	14-5000079	SHAFT B	1				
25	14-3000169	CLUTCH ASS'Y (LF180)	1				
26	14-5000665	SCREW	4				
27	14-5000491	GEAR CASE	1				
28	14-PSW2201	WRENCH BOLT	2				
29	14-PFE1212	2ND IDLE GEAR B	4				
30	14-PFE1915	CENTER PIN	1				
32	14-PFE1103	1ST GEAR HOLDER ASSY B	1				
33	14-5000134	1ST IDLE GEAR	3				
34	14-PFE1947	WASHER	1				
35	14-PFE1903	SNAP RING	1				