


A6500PS

Rev 1.0



A6500PS

Ref#	Part Name	Part#	Ref#	Part Name	Part#
	Transmission Assembly 1 – 38 (w/o 10,34-37)	41-A65PSX-TM	35	Washer 0.1	41-XXX
	Torque Adjusting Nut Assembly 1 – 3	41-CL65-NT	36	Bearing for Gear Support	41-CL65PS-0370
1	Torque Adjusting Nut	41-CL65-0010	37	Center Pin B	41-CL65PS-0471
2	Knotting Ball 3ø	41-BALL-03	39	Pinion Gear	41-A65PS-0330
3	Knotting Ball Band	41-CL65-0030	40	Motor	41-A65PS-0340
4	Torque Adjusting Spring	41-CL65-0040	41	Motor Front Cover	41-CL65-0360
5	Clutch Cover	41-A65-0050	42	Set Screw 3x5.5	41-STB30X055
6	Clutch Cover Set Screw 3x5.5 (x2)	41-STB30X055	43	Magnet Case	41-A65-2340
7	Mark Label	41-A65-0070	44	Motor Case	41-CL65-0440
8	Torque Adjusting Bolt Set Screw (x3)	41-STP26X080	45	Set Screw 3x4	41-STB30X040
9	Torque Adjusting Bolt	41-CL65-0090	46	Ring Stopper	41-CL65-0370
10	Limit Switch	41-CL4-0230	47	Wave Washer	41-CL65-0380
	Joint Shaft Assembly 11 – 15	41-CL65X-JS	48	Rotor Adjusting Washer 0.1	41-CL65-0390
11	Collar Stopper	41-CL65-0110	49	Rotor Adjustment Washer 0.2	41-CL65-0400
12	Joint Shaft Collar	41-CL65X-0120	50	Motor Bearing	41-CL65-0410
13	Collar Spring	41-CL65-0130	51	Rotor	41-A65PS-0420
14	Bit Lock Ball 2.0ø (x3)	41-BALL-02		Motor End Cover Assembly 46,50, 52-57	41-A65-3470
15	Joint Shaft (HEX Shank)	41-CL65PSX-0160	52	Motor End Cover	41-CL65-0470
16	Clutch Supporter	41-CL65-0160	53	Capacitor	41-CL4-0441
17	Joint Shaft Lock Pin 2x9.8	41-CLPS-0160	54	Condenser 682KG	41-CL3NL-0440
18	Joint Shaft Set Screw 3x3	41-SH30X030	55	Set Screw 2.6x20	41-STB26X200
19	Intermediary Spring	41-CL65PS-0190	56	Carbon Brush	41-CL65-0490
20	Switch Intermediary	41-CL65PS-2000	57	Carbon Brush Cap	41-A65-0500
21	Gear Case Set Ring	41-CL65-0190	58	Set Screw 3x8	41-STB30X080
22	O-Ring	41-CL65-0200		Switch Assembly 59-69	41-A65PS-SW
	Gear Assembly 23 – 35	41-A65-GR	59	Set Screw 2.6x5	41-STB26X050
23	Clutch Ball 5.5ø	41-BALL-055	60	Switch Cover A & B	41-A65-0530
24	Gear Case	41-CL65PS-0220	61	Terminal Holder	41-CL4-0550
25	Cam Roller 5x7	41-CL65-0230	62	Noise Filter B	41-A45-0630
26	Internal Gear	41-A65PS-0240	63	For/Rev Switch	41-CL65-0590
27	Thrust Bearing 6x12 (x2)	41-CL65-0250	64	Starting Switch	41-CL65PS-0610
28	Lower Planet Cage	41-A65PS-0260	65	5 Pin Connector	41-CL4-0580
29	Planet Gear (x6)	41-A65PS-0270	66	Set Screw 3x1.8	41-STB30X180
30	Gear Plate	41-A65-0680	67	Side Cover	41-CL65PS-0640
31	Thrust Washer	41-CL4-0290	68	Hanger	41-CL65-0650
32	Center Pin	41-A65PS-0300	69	Mark Label	41-CL65PS-8060
33	Upper Planet Cage	41-A65PS-0310	70	5-Core Cord w/Connector in both ends	41-CL65-0660
34	Gear Seal	41-A65PS-0320	71	Free-up Belt	41-CL65-0670