


A5000

Rev 1.0



A5000

Ref#	Part Name	Part#	Ref#	Part Name	Part#
	Transmission Assembly 1 – 33 (w/o 23)	41-A5-TM	31	Upper Planet Cage	41-A5-0310
	Torque Adjusting Nut Assembly 1 – 5	41-CL4-NT	32	Pinion Gear	41-A5-0320
1	Nut Cover Stopper	41-CL4-0010	33	Grease Seal	41-A5-0330
2	Nut Cover	41-CL4-0020		Motor	
3	Nut Cover Spring	41-CL4-0030	34	Motor Front Panel Set Screw 3x5	41-STP30X050
4	Torque Adjusting Nut	41-CL4-0040	35	Motor Front Panel	41-CL4-0350
5	Knotting Ball 3ø	41-BALL-03	36	Motor	41-A45-0360
6	Torque Adjusting Spring 2.0ø (Green)	41-A5-0060	37	Magnet Case	-----
7	Torque Adjusting Bolt Set Screw (x2)	41-STP26X100	38	-----	-----
8	Torque Adjusting Bolt	41-CL4-0080	39	Wave Washer	41-A45-0370
	Joint Shaft Assembly 9 - 13	41-A45-JS	40	Rotor Adjusting Washer 0.1	41-A45-0380
9	Collar Stopper	41-CL4-0090		Motor End Cover Assembly 41 – 47	41-A45-3400
10	Joint Shaft Collar	41-CL4-0100	41	Stop Ring	41-A45-0390
11	Collar Spring	41-CL4-0110	42	Motor End Cover	41-A45-0400
12	Bit Lock Ball 2ø	41-BALL-02	43	Motor End Cover Set Screw 1.7x10	41-STP17X100
13	Joint Shaft	41-A45-0130	44	Carbon Brush	41-A45-0420
14	Joint Shaft Lock Pin 2x9	41-SR20X090	45	Carbon Brush Cap	41-A45-0430
15	Joint Shaft Set Screw 3x3	41-SH30X030	46	Noise Filter A	41-CL4-0441
16	Clutch Supporter	41-CL4-0160	47	Motor Bearing	41-A45-0450
	Gear Assembly 17 – 33 (w/o 23)	41-A5-GR	48	Rotor	41-A45-0460
17	Thrust Bearing Ball	41-A45-0170	49	Body Case A & B	41-A45-0470
18	Clutch Ball Rod	41-A45-0180	50	Motor Case Set Screw 2.6x6	41-STP26X060
19	Clutch Ball 5ø	41-BALL-05	51	Motor Case Joint Screw 2.6x12	41-STPB26X120
20	Gear Case Plate	41-CL4-0200	52	Switch Lever	41-A45-0500
21	Gear Case	41-A45-0210	53	Switch Lever Spring	41-CL4-0510
22	Gear Case Set Screw 2.6x5	41-STP26X050	54	Switch Lever Plunger	41-CL4-0520
23	Limit Switch	41-CL4-0230		Switch Assembly 22, 55 - 62	41-A5-SW
24	Internal Gear	41-A5-0240	55	Switch Cover A & B	41-A45-0530
25	Cam Roller	41-A45-0250	56	Name Plate	41-A5-0540
26	Lower Planet Cage	41-A5-0260	57	Terminal Holder	41-CL4-0550
27	Planet Gear (x8)	41-A5-0270	58	Noise Filter B	41-A45-0630
28	Gear Plate	41-A5-0640	59	For/Rev Switch	41-CL4-0560
29	Gear Washer	41-CL4-0290	60	Starting Switch	41-CL4-0570
30	Center Pin	41-A45-0300	61	5-Pin Connector	41-CL4-0580
			62	Hanger	41-CL4-0590
			63	Free-Up Belt	41-CL4-0600
			64	5-Core Cord w/Connector in both ends	41-CL4-0610