


# BL3000

Version 1.1



# BL3000

| No. | Part Number        | Description                           | Qty. |
|-----|--------------------|---------------------------------------|------|
| 1   | 41-BL3A-0720       | Torque Adjusting Protect Cover        | 1    |
| 2   | 41-BL3A-0010       | Torque Adjusting Nut                  | 1    |
| 3   | 41-BL3-0020        | Torque Adjusting Spring holder        | 1    |
| 4   | 41-BL3A-0040       | Torque Adjusting Spring               | 1    |
| 5   | 41-BL3-0160        | Clutch Supporter                      | 1    |
| 6   | 41-BL3-0230        | Torque Adjusting Bolt                 | 1    |
| 7   | 41-CL4-0090        | Collar Stopper                        | 1    |
| 8   | 41-BL4-0120        | Collar Spring                         | 1    |
| 9   | 41-BL3A-0070       | Joint Shaft Collar                    | 1    |
| 10  | 41-BL3A-0090       | Joint Shaft                           | 1    |
| 11  | 41-BL3A-0130       | Push Spring                           | 1    |
| 12  | 41-BALL-02         | Steel Ball 2.0                        | 2    |
| 13  | 41-MSPF26060NIGP   | Set Screw 2.6X60                      | 3    |
| 14  | 41-BALL-015        | Steel Bal 1.5                         | 3    |
| 15  | 41-BL3A-0150       | Joint                                 | 1    |
| 16  | 41-BL3A-0160       | Pin Protect Collar                    | 1    |
| 17  | 41-BL3-0250        | Washer 5X9X0.9                        | 1    |
| 18  | 41-BL3-0100        | Thrust Bearing                        | 1    |
| 19  | 41-BL3-0070        | Spacer Shaft (x 2)                    | 2    |
| 20  | 41-BALL-04         | Steel Ball 4.0                        | 2    |
| 21  | 41-BL3-0220        | Gear Case                             | 1    |
| 22  | 41-CL4-0250        | Cam Roller                            | 2    |
| 23  | 41-BL3-0390        | Cam Plate                             | 1    |
| 24  | 41-BL3-0030        | Lower Planet Shaft                    | 1    |
| 25  | 41-CL65PS-0150     | Center Pin                            | 1    |
| 26  | 41-BL3-0060        | Internal Gear                         | 1    |
| 27  | 41-BL3-0140        | Lower Floor                           | 1    |
| 28  | 41-BL3-0150        | Planet Gear                           | 8    |
| 29  | 41-BL3-0040        | Upper Floor Gear                      | 1    |
| 30  | 41-BL3-0130        | Upper Planet Cage                     | 1    |
| 31  | 41-BL3-0321        | Pinion Gear                           | 1    |
| 32  | 41-BL3-0050        | Cup Ring                              | 1    |
| 33  | 41-MSPF26060NIGP   | Set Screw 2.6X60                      | 3    |
| 34  | 41-CL65PS-0150     | Hold Pin                              | 1    |
| 35  | 41-SH26X030        | Set Screw 2.6x30                      | 1    |
| 36  | 41-BL3-0402        | Body Case A&B                         | 1    |
| 37  | 41-BL3-0450        | For/Rev Switch Lever                  | 1    |
| 38  | 41-BL3-0530        | Name Label                            | 1    |
| 39  | 41-BL3-0500        | Switch Lever                          | 1    |
| 40  | 41-CL4-0510        | Switch Lever Spring                   | 1    |
| 41  | 41-BL3-0080        | Motor Front Panel                     | 1    |
| 42  | 41-BL3-0361        | Motor                                 | 1    |
| 43  | 41-SPP20X050       | Set Screw 2.6x50                      | 3    |
| 44  | 41-BL3-CC1         | Circuit Assy                          | 1    |
| 45  | 41-CL4-0590        | Hanger                                | 1    |
| 46  | 41-CL4-0611        | 5-Core Cord W/Connectors In Both Ends | 1    |
| 47  | 41-MSPF26060NIGP   | Set Screw 2.6X60                      | 2    |
| 48  | 41-BL3-0170        | Switch Lever Plunger                  | 1    |
| 49  | 41-B0HD5F35120NITP | Set Screw 3.5X120                     | 1    |
| 50  | 41-MSPF26060NIGP   | Set Screw 2.6x60                      | 1    |