



Recommendations for Maintenance:

Please, note it is important to make sure the tool has clean, dry and lubricated air at the recommended pressure supplied to it. (Please consult the service manual for further instructions)

The pulse tool requires preventive maintenance like oil changes and have the parts inspected periodically. It is recommended to make the first preventive maintenance at 250,000 pulses-seconds or 6 months, which either one occurs first. The tool's performance should be evaulated. The oil needs to be changed. Inspect all the soft parts of the pulse unit (the soft parts are referenced as the "Repair Kit" - see parts list page 2). The Repair Kit includes all the necessary parts and it is recommend to be performed every six months (unless parts are in good condition). If the tool fails before the 250,000 pulses-seconds then the pulse unit needs to be rebuilt, with the "Repair Kit" and "Service Kit" (see parts list page 2). Caution: prevailing torque, which makes that the tool start pulsing early, reduces the life of the Oil & O-rings of the pulse unit. A pulse-second is not every second the tool is running, only when it's "pulsing" and applying torque. On typical applications the tool should run down freely until fastener is snug and then the tool starts pulsing until it reaches the preset torque. When operating the tool on the fastener, start counting once the tool begins pulsing. You can use a watch with a second hand and time it until the tool shuts-off. Use the information to calculate how many pulse-seconds the tool performs per application each day. Then perform some basic math to calculate the tool's maintenance schedule. Use this formula.

Pulsing Seconds + Total of Pulsing Time = No Cycles

NOTE: Please include the rework, reverse, or retightening time is involve on the operation to calculate the accurate pulsing time. Here is an example:

Pulsing Time = 2 seconds Pulses- seconds recommended = 250.000

250,000 pulses-sec \div 2 sec = 125,000 cycles

Using the information above, you can estimate the maintenance period for the tool by using this formula:

No of Fasteners	Pulsing Time per Fastener	No of Parts Assembled per Day	Calculation	Maintenance Period
7	2 seconds	300	125,000 /(300*7) = 59	59 days



by mountz

Part No.	Description	Q'ty	Index No.	Part No.	Description	Q'ty
63-757-026	Anvil Collar	1	43	63-140-307	Rear Cover	1
63-I40SD-419	Hold Spacer	1	44	63-00-41144	O-Ring	2
63-I40SD-418	Spring	1	45	63-I40-101	Motor Housing	1
63-I40SD-417	Quick change Hold	1	46	63-I40S-108	Bushing	4
63-I100-410	Greasing Screw	1	47	63-I40S-102	Hanger	1
63-00-4153	O-Ring	1	48	63-00-41146	O-Ring	1
63-I40S-201	Pulse Unit Housing	1	49	63-I40-104	Nut	1
63-I40S-202	Bushing	1	50	63-140-504	Trigger	1
63-I40S-424	Washer	1	51	63-00-3354	Spring Pin	1
63-I40S-401	Pulse Cylinder Seat	1	52	63-00-0505	Screw	2
63-00-41127	O-Ring	2	53	63-I100-503	Regulator Knob	1
63-170-410	Greasing Screw	1	54	63-00-4101	O-Ring	1
63-00-41113	O-Ring	2	55EA	63-IS40-505B	Valve Stem	1
63-00-3318	Spring Pin	2	56EA	63-I100-508B	Bushing	1
63-I40S-403-B	Front Cover	1	57EA	63-00-41199	O-Ring	1
63-00-2602	X-Ring	1	58EA	63-I40-507B	Spring	1
63-I40S-408	Front Plate	1	59	63-I100-506	Spring	1
63-00-3813	Steel Ball	3	60EB	63-IS40-502	F/R Valve	1
63-I40SD-405	Anvil	1	61	63-I40-501	Valve Sleeve	1
	Roller	2	62	63-00-41111	O-Ring	2
63-I40S-406-B	Drive Blade			63-I100-511		1
63-I40S-407	Spring			63-00-41145		1
	Valve Screw	1		63-140-601	Muffler	1
	Valve	1		63-140-603	Exhaust Deflector	1
		1				
63-00-3435		2	67	63-I40-604B	Air Inlet 1/4"-19PT	1
		1				
	,	2	68C			1
63-00-3436	Pin	1	69C	63-IS40S-421	Pressure Valve	1
	Rear Plate	1	70C	63-I40S-453		1
63-I40S-423	Washer	1	71C	63-I40S-454	1 3	1
63-I40S-402	Lock Nut	1	72EA	63-140-409		1
		1	73EB			1
		1	-			1
	_	1	•			1
		1				-
		1		55 1162 511 1112		
		1				
	Rotor Blade	9	•	63-I40DRK-MZ		
	Rear Plate	1		oo Hobrarama	11(2); 13(2) ; 16; 22(2); 25;	
63-00-2356	Ball Bearing	1	•	63-140-451	,	
		1		55 1 15 151	paico oii	
	63-140SD-419 63-140SD-418 63-140SD-418 63-140SD-417 63-1100-410 63-00-4153 63-140S-201 63-140S-202 63-140S-424 63-140S-401 63-00-41127 63-170-410 63-00-41113 63-00-3318 63-140S-403-B 63-00-2602 63-140S-408 63-00-3813 63-140S-405 63-140S-406-B 63-140S-407 63-180-411 63-180-411 63-180-411 63-1940S-412-B 63-00-3435 63-140S-404-B 63-00-3435 63-140S-404-B 63-00-3436 63-140S-402 63-140S-402 63-140S-306 63-00-2348 63-140S-306 63-00-3324 63-00-3356 63-140S-304 63-140S-304 63-140S-305 63-00-2356 63-00-2356 63-00-2356	63-I40SD-419 Hold Spacer 63-I40SD-418 Spring 63-I40SD-417 Quick change Hold 63-I100-410 Greasing Screw 63-00-4153 O-Ring 63-I40S-201 Pulse Unit Housing 63-I40S-202 Bushing 63-I40S-424 Washer 63-I40S-401 Pulse Cylinder Seat 63-00-41127 O-Ring 63-I70-410 Greasing Screw 63-00-41113 O-Ring 63-00-3318 Spring Pin 63-I40S-403-B Front Cover 63-00-2602 X-Ring 63-I40S-408 Front Plate 63-00-3813 Steel Ball 63-I40S-452 Roller 63-I40S-406-B Drive Blade 63-I40S-407 Spring 63-I80-411 Valve Screw 63-00-3415 Pin 63-I40S-404-B Pulse Cylinder 63-00-3407 Pin 63-00-3435 Pin 63-I40S-404-B Pulse Cylinder 63-00-3407 Pin 63-00-3436 Pin 63-I40S-402 Lock Nut 63-I40S-402 Lock Nut 63-I40S-306 Lock Nut 63-00-3324 Spring Pin 63-00-3324 Spring Pin 63-00-3324 Spring Pin 63-00-3324 Spring Pin 63-140S-303 Rotor 63-I40S-304 Rotor Blade 63-I40-305 Rear Plate 63-00-2356 Ball Bearing	63-I40SD-419	63-757-026	63-757-026 63-140SD-419 Hold Spacer 1	63-757-026 63-140SD-419 63-140SD-419 63-140SD-418 Spring 1 45 63-140-101 63-140SD-417 Quick change Hold 63-140SD-417 Greasing Screw 1 47 63-140S-102 Hanger 63-140S-103 63-140S-103 63-140S-102 Hanger 63-140S-101 63-140S-102 Hanger 63-140S-201 63-140S-201 Pulse Unit Housing 1 48 63-00-4114 60-Ring 63-140S-201 63-140S-202 Bushing 1 50 63-140S-201 Pulse Unit Housing 1 50 63-140S-202 Bushing 1 50 63-140S-202 Bushing 1 50 63-140S-304 Bushing 1 50 63-140S-304 Bringer 63-140S-305 Bringer 6