



Recommendations for Maintenance:

Please, note it is important to make sure the tool has clean, dry and lubricated air at the recommended pressure supplied to it. (Please consult the service manual for further instructions)

The pulse tool requires preventive maintenance like oil changes and have the parts inspected periodically. It is recommended to make the first preventive maintenance at 250,000 pulses-seconds or 6 months, which either one occurs first. The tool's performance should be evaulated. The oil needs to be changed. Inspect all the soft parts of the pulse unit (the soft parts are referenced as the "Repair Kit" - see parts list page 2). The Repair Kit includes all the necessary parts and it is recommend to be performed every six months (unless parts are in good condition). If the tool fails before the 250,000 pulses-seconds then the pulse unit needs to be rebuilt, with the "Repair Kit" and "Service Kit" (see parts list page 2). Caution: prevailing torque, which makes that the tool start pulsing early, reduces the life of the Oil & O-rings of the pulse unit. A pulse-second is not every second the tool is running, only when it's "pulsing" and applying torque. On typical applications the tool should run down freely until fastener is snug and then the tool starts pulsing until it reaches the preset torque. When operating the tool on the fastener, start counting once the tool begins pulsing. You can use a watch with a second hand and time it until the tool shuts-off. Use the information to calculate how many pulse-seconds the tool performs per application each day. Then perform some basic math to calculate the tool's maintenance schedule. Use this formula.

Pulsing Seconds ÷ Total of Pulsing Time = No Cycles

NOTE: Please include the rework, reverse, or retightening time is involve on the operation to calculate the accurate pulsing time. Here is an example:

Pulsing Time = 2 seconds

Pulses- seconds recommended = 250,000

250,000 pulses-sec \div 2 sec = 125,000 cycles

Using the information above, you can estimate the maintenance period for the tool by using this formula:

| No of Fasteners | Pulsing Time per Fastener | No of Parts Assembled per Day | Calculation | Maintenance Period |
|--------------------|------------------------------|-------------------------------|-----------------------|--------------------|
| 7 | 2 seconds | 300 | 125,000 /(300*7) = 59 | 59 days |



by mountz

| Indov | | | | Indov | | | 1 | |
|-----------------------------------|--------------------|---|------|-------|----------------|-------------------------------|------|--|
| Index | Part No. | Description | Q'tv | Index | Part No. | Description | Q'ty | |
| No. | | - | | No. | | ' | | |
| 1 2 3 4 5EB | 63-I50R-706 | Lock Nut | 1 | 52 | 63-00-2348 | Ball Bearing | 1 | |
| 2 | 63-00-41134 | O-Ring | 1 | 53 | 63-00-3324 | Spring Pin | 1 | |
| 3 | 63-00-2358 | Ball Bearing | 1 | 54 | 63-I70S-302 | Cylinder | 11 | |
| 4 | 63-I50R-711 | Washer | 1 | 55 | 63-00-3326 | Spring Pin | 1 | |
| 5EB | 63-I50R-705-B | Shaft Gear | 1 | 56 | 63-I70S-303 | Rotor | 1 | |
| 6 7 | 63-I50R-707 | Shaft | 1 | 57 | 63-I70S-304 | Rotor Blade | 9 | |
| 7 | 63-00-2357 | Ball Bearing | 1 | 58 | 63-I50S-305 | Rear Plate | 1 | |
| 8 9 | 63-I90-410 | Greasing Screw | 1 | 59 | 63-00-2356 | Ball Bearing | 1 | |
| 9 | 63-00-4153 | O-Ring | 1 | 60 | 63-I40S-310 | Air inlet Plate | 1 | |
| 10 | 63-I50R-701 | Angle Housing | 1 | 61 | 63-305F-034 | Spring | 1 | |
| | 63-00-0605 | Set Screw | 1 | 62 | 63-IS40S-502 | F/R Valve | 1 | |
| 12 | 63-I50R-704 | Main Shaft Gear | 1 | 63 | 63-00-41146 | O-Ring | 1 | |
| 13 | 63-I50R-712 | Washer | 1 | 64 | 63-00-4121 | O-Ring | 1 | |
| 14 15 | 63-00-2352 | Ball Bearing | 2 | 65 | 63-IS40S-312 | Valve Washer | 1 | |
| 15 | 63-I50R-709 | Lock Nut | 1 | 66 | 63-00-3824 | Steel Ball | 1 | |
| 16 | 63-I50R-702 | Lock Nut | 1 | 67 | 63-IS40S-313 | Spring | 1 | |
| 17 | 63-I50R-708 | Anvil Collar | 1 | 68 | 63-IS40S-311 | Valve | 1 | |
| 18 | 63-00-3430 | Pin | 1 | 69 | 63-00-41125 | O-Ring | 1 | |
| 10 | 63-I70R-201 | Pulse Unit Housing | 1 | 70 | 63-I40S-309 | Seat | 1 | |
| 20 | 63-I40S-202 | Bushing | 1 | 71 | 63-I70S-101 | Motor Housing | 1 | |
| 21 | 63-I40S-424 | Washer | 1 | 72 | 63-00-0507 | Screw | 1 | |
| 22 | 63-170-401 | Pulse Cylinder Seat | 1 | 73 | 63-I40S-503 | Regulator Knob | 1 | |
| 20 21 22 23D 24 25 | 63-00-41160 | O-Ring | 2 | 74 | 63-I40S-102 | Hanger | 1 | |
| 24 | 63-170-410 | Greasing Screw | 1 | 75 | 63-I40S-509 | Bushing | 1 | |
| 25 | 63-00-41113 | O-Ring | 3 | 76 | 63-IS40S-510 | Pin | 1 | |
| 26 | 63-00-3318 | Spring Pin | 2 | 77 | 63-I40S-504 | Trigger | 1 | |
| 26 27 28 29 30 | 63-170-403 | Front Cover | 1 | 78 | 63-I40S-108 | Bushing | 2 | |
| 28 | 63-170-408 | Front Plate | 1 | 79 | 63-00-3306 | Spring Pin | 1 | |
| 29 | 63-170-409 | Back Up Ring | 1 | 80 | 63-I40S-103 | Housing Rubber | 1 | |
| 30 | 63-00-2602 | X-Ring | 1 | 81 | 63-I40S-508 | Bushing | 1 | |
| 31 | 63-I70R-405 | Anvil | 1 | 82 | 63-305C-021 | Valve Stem | 1 | |
| 32B | 63-170-452 | Roller | 2 | 83 | 63-I40S-507 | Spring | 1 | |
| 33B | 63-I70-406-B | Drive Blade | 2 | 84 | 63-I40S-601 | Muffler | 1 | |
| 34 | 63-170-407 | Spring | 2 | 85 | 63-I40S-603 | Exhaust Deflector | 1 | |
| | 63-IS40-450 | Block Valve | 1 | | 63-I40S-604A | Air Inlet 1/4"PF-19 | | |
| | 63-180-411 | Screw | 1 | 86 | 63-I40S-604B | Air Inlet 1/4"PT-19 | 1 | |
| 37EA | 63-IS70-412-C | Valve | 1 | | 63-I40S-604C | Air Inlet 1/4"NPT-18 | | |
| 38C | 63-00-41173 | O-Ring | 2 | 87 | 63-00-3509 | Snap Ring | 1 | |
| 39 | 63-00-3813 | Steel Ball | 2 | 88C | 63-I70S-453 | Spring | 1 | |
| 40FA | 63-IS70R-425-C | Spring | 1 | 89C | 63-I40S-454 | Block Cap | 1 | |
| 41 | 63-00-3435 | Pin | 2 | 90 | 63-00-41130 | O-Ring | 1 | |
| 41 42 43C | 63-00-3436 | Pin | 1 | 91D | 63-00-41127 | O-Ring | 1 | |
| 43C | 63-I70-404-B | Pulse Cylinder | 1 | 92EC | 63-180-422 | Back Up Ring | 1 | |
| 44 | 63-00-3407 | Pin | 2 | • | 63-IS70RSK-MZ | Service kit :Index No- | | |
| 45EA | 63-IS70-415-C | Rear Plate | 1 | | | 5EB;12;28;32B(2);33B(2); | | |
| 46 | 63-I40S-423 | Washer | 1 | | | 45EA:57(9):67;81;82;83 | | |
| | 63-IS40S-421 | Pressure Valve | 2 | • | 63-IS70RRK-MZ | Repair kit :Index No- | | |
| 48D | 63-IS130-314 | Shut Off Stem | 1 | | | 23D(2); 25(2); 29; 30; 34(2); | | |
| 49EA | 63-IS150-317 | Spring | 1 | | | 38C(2); 90 | | |
| | 63-170-402 | Lock Nut | 1 | • | 63-140-451 | Impulse Oil | | |
| 51 | 63-I70S-306 | Lock Nut | 1 | | 33 . 13 . 13 . | | | |
| • | | Pulse unit : Index No- | | | | | | |
| | SS 107 OIX TOOMONI | 22,23D,24,25,26,27,28,29,30,31,32B,33B,34,35B,36EC,37EA,38C,39,40EA,41,42,43C,44,45EA,47C,50, | | | | | | |
| | | 88C,89C,90,92EC | | | | | | |
| | | 20,030,30,32EO | | | | | | |

Rev: Nov12 www.mountztorque.com 2