
FAQ FOR TB BREAK-OVER WRENCHES

Q1: What fastening applications are preset wrenches used in?

A1: Preset torque wrenches are ideal for fastening applications where operators repeatedly assemble parts at the same torque setting.

Q2: Does the TB wrench have an external torque scale or adjustment mechanism?

A2: A preset wrench doesn't have an external torque adjustment scale. These tools have an internal torque adjustment mechanism for setting the torque value using a hex key and a torque analyzer.

Q3. How do you set the torque for the preset wrench?

A3. It can be preset using a torque analyzer. Or you can order the tool at a preset torque value.

Q4. Can the preset torque value be changed for a new fastening application?

A4. Yes, the wrench can be internally adjusted and calibrated to a new preset torque value. It would require a torque analyzer or the tool being sent to the calibration lab.

Q5. What is the ISO standard for recalibrating hand wrenches?

A5. ISO 6789-1:2017 calls for a maximum of 5,000 before recalibration.

Q6. What is the difference between the TB and TBIH wrench models

A6. The TB wrench comes with a head permanently attached to it. It is not removable. The TBIH break-over wrench allows you to remove the wrench head and add another option.

Q7. Can the TB only be calibrated in CW & CCW directions?

A7. The TB is calibrated in the CW direction only.

Q8. Is the TB available with different types of wrench heads and sizes?

A8. Yes, the TB is a wrench that you configure. When ordering this wrench, you can select the head type and size (options vary per model).

Q9. Does Mountz offer the capability to produce custom-size heads for application?

A9. Yes, Mountz does produce custom-size heads.

