



Recommendations for Maintenance:

Please, note it is important to make sure the tool has clean, dry and lubricated air at the recommended pressure supplied to it. (Please consult the service manual for further instructions)

The pulse tool requires preventive maintenance like oil changes and have the parts inspected periodically. It is recommended to make the first preventive maintenance at 250,000 pulses-seconds or 6 months, whichever one occurs first. The tool's performance should be evaluated. The oil needs to be changed. Inspect all the soft parts of the pulse unit (the soft parts are referenced as the "Repair Kit" - see parts list page 2). The Repair Kit includes all the necessary parts and it is recommended to be performed every six months (unless parts are in good condition). If the tool fails before the 250,000 pulses-seconds then the pulse unit needs to be rebuilt, with the "Repair Kit" and "Service Kit" (see parts list page 2).
 Caution: prevailing torque, which makes that the tool start pulsing early, reduces the life of the Oil & O-rings of the pulse unit. A pulse-second is not every second the tool is running, only when it's "pulsing" and applying torque. On typical applications the tool should run down freely until fastener is snug and then the tool starts pulsing until it reaches the preset torque. When operating the tool on the fastener, start counting once the tool begins pulsing. You can use a watch with a second hand and time it until the tool shuts-off. Use the information to calculate how many pulse-seconds the tool performs per application each day. Then perform some basic math to calculate the tool's maintenance schedule. Use this formula.

$$\# \text{ Pulsing Seconds} \div \text{Total of Pulsing Time} = \text{No Cycles}$$

NOTE: Please include the rework, reverse, or retightening time is involve on the operation to calculate the accurate pulsing time. Here is an example:

Pulsing Time = 2 seconds
 Pulses- seconds recommended = 250,000

$$250,000 \text{ pulses-sec} \div 2 \text{ sec} = 125,000 \text{ cycles}$$

Using the information above, you can estimate the maintenance period for the tool by using this formula:

No of Fasteners	Pulsing Time per Fastener	No of Parts Assembled per Day	Calculation	Maintenance Period
7	2 seconds	300	$125,000 / (300 \times 7) = 59$	59 days

Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	63-757-026	Anvil Collar	1	47	63-00-2356	Ball Bearing	1
2	63-I40SD-419	Hold Spacer	1	48	63-00-41144	O-Ring	2
3	63-I40SD-418	Spring	1	49	63-00-41135	O-Ring	1
4	63-I40SD-417	Quick Change Hold	1	50	63-IS40-307	Rear Cover	1
5	63-I100-410	Greasing Screw	1	51	63-IS40-524	Valve Seat	1
6	63-00-4153	O-Ring	1	52	63-00-41145	O-Ring	2
7	63-I60S-201	Pulse Unit Housing	1	53	63-IS40S-312	Washer	1
8	63-I40S-202	Bushing	1	54	63-00-3824	Steel Ball	1
9	63-I40S-424	Washer	1	55	63-IS40S-313	Spring	1
10	63-I60S-401	Pulse Cylinder Seat	1	56	63-IS40S-311	Valve	1
11	63-I70-410	Greasing Screw	1	57	63-IS40-518	Seat	1
12	63-00-41113	O-Ring	4	58	63-IS60-101	Motor Housing	1
13	63-00-3318	Spring Pin	2	59	63-I40S-108	Bushing	4
14	63-00-41127	O-Ring	2	60	63-IS100-609	Screw	1
15EA	63-I40S-403-B	Front Cover	1	61	63-I40S-102	Hanger	1
16	63-00-2602	X-Ring	1	62	63-00-41146	O-Ring	1
17	63-I40S-411	Valve Screw	1	63	63-00-4169	O-Ring	1
18	63-00-3435	Pin	2	64	63-I40-104	Nut	1
19	63-I40S-408	Front Plate	1	65	63-I40-504	Trigger	1
20B	63-IS60SD-405	Anvil	1	66	63-00-3354	Spring Pin	1
21	63-00-3813	Steel Ball	4	67	63-00-0505	Screw	2
22B	63-I60S-406-B	Drive Blade	2	68	63-I100-503	Regulator Knob	1
23B	63-I60S-452	Roller	2	69	63-00-4101	O-Ring	1
24	63-I40S-407	Spring	2	70EA	63-IS40-505B	Valve Stem	1
25B	63-IS40-450	Block Valve	1	71EA	63-I100-508B	Bushing	1
26EA	63-IS60S-412-C	Valve	1	72EA	63-00-41199	O-Ring	1
27	63-00-41130	O-Ring	1	73EA	63-I40-507B	Spring	1
28EA	63-IS60SD-425-C	Spring	1	74	63-I100-506	Spring	1
29C	63-I60S-404-B	Pulse Cylinder	1	75	63-IS40-502	F/R Valve	1
30	63-00-3436	Pin	1	76	63-I40-501	Valve Sleeve	1
31	63-00-3407	Pin	2	77	63-00-41111	O-Ring	2
32EA	63-IS40S-415-C	Rear Plate	1	78	63-I40-601	Muffler	1
33C	63-00-41173	O-Ring	2	79	63-I40-603	Exhaust Deflector	1
34C	63-IS40S-421	Pressure Valve	2		63-I40-604A	Air Inlet 1/4"-19PF	
35	63-IS60-314	Shut Off Stem	1	80	63-I40-604B	Air Inlet 1/4"-19PT	1
36	63-IS40S-317	Spring	1		63-I40-604C	Air Inlet 1/4"-18NPT	
37	63-I40S-423	Washer	1	81	63-I100-511	Pin	1
38	63-I40S-402	Lock Nut	1	82C	63-I60S-453	Spring	1
39	63-I40S-306	Lock Nut	1	83C	63-I40S-454	Block Cap	1
40	63-00-2348	Ball Bearing	1	84EA	63-I40-409	Back-Up Ring	1
41	63-00-3324	Spring Pin	1	※	63-IS60DRK-E05A	Repair kit :Index No- 12(2); 14(2); 16; 24(2); 27; 33C(2); 84EA	
42	63-I60-302	Cylinder	1				
43	63-00-3356	Spring Pin	1	※	63-IS60DSK-E05A	Service kit :Index No- 19;22B(2);23B(2);32EA; 45(9); 55; 71EA; 72EA; 73EA	
44	63-I60S-303	Rotor	1				
45	63-I60S-304	Rotor Blade	9				
46	63-I40-305	Rear Plate	1	※	63-IS60SD-400ASM	Pulse Unit	
					63-01-0505FL	Accessories Kits Included	
					63-Pulse Tool Fluid, 125ml	Pulse Tool Fluid, 125ml	