



Recommendations for Maintenance:

Please, note it is important to make sure the tool has clean, dry and lubricated air at the recommended pressure supplied to it. (Please consult the service manual for further instructions)

The pulse tool requires preventive maintenance like oil changes and have the parts inspected periodically. It is recommended to make the first preventive maintenance at 250,000 pulses-seconds or 6 months, whichever one occurs first. The tool's performance should be evaluated. The oil needs to be changed. Inspect all the soft parts of the pulse unit (the soft parts are referenced as the "Repair Kit" - see parts list page 2). The Repair Kit includes all the necessary parts and it is recommended to be performed every six months (unless parts are in good condition). If the tool fails before the 250,000 pulses-seconds then the pulse unit needs to be rebuilt, with the "Repair Kit" and "Service Kit" (see parts list page 2).
 Caution: prevailing torque, which makes that the tool start pulsing early, reduces the life of the Oil & O-rings of the pulse unit. A pulse-second is not every second the tool is running, only when it's "pulsing" and applying torque. On typical applications the tool should run down freely until fastener is snug and then the tool starts pulsing until it reaches the preset torque. When operating the tool on the fastener, start counting once the tool begins pulsing. You can use a watch with a second hand and time it until the tool shuts-off. Use the information to calculate how many pulse-seconds the tool performs per application each day. Then perform some basic math to calculate the tool's maintenance schedule. Use this formula.

$$\# \text{ Pulsing Seconds} \div \text{Total of Pulsing Time} = \text{No Cycles}$$

NOTE: Please include the rework, reverse, or retightening time involved on the operation to calculate the accurate pulsing time. Here is an example:

Pulsing Time = 2 seconds
 Pulses- seconds recommended = 250,000

$$250,000 \text{ pulses-sec} \div 2 \text{ sec} = 125,000 \text{ cycles}$$

Using the information above, you can estimate the maintenance period for the tool by using this formula:

No of Fasteners	Pulsing Time per Fastener	No of Parts Assembled per Day	Calculation	Maintenance Period
7	2 seconds	300	$125,000 / (300 \times 7) = 59$	59 days

Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	63-757-026	Anvil Collar	1	44	63-I60S-303	Rotor	1
2	63-I40SD-419	Hold Spacer	1	45	63-I60S-304	Rotor Blade	9
3	63-I40SD-418	Spring	1	46	63-I50S-305	Rear Plate	1
4	63-I40SD-417	Quick Change Hold	1	47	63-00-2356	Ball Bearing	1
5	63-I100-410	Greasing Screw	1	48	63-I40S-310	Air Inlet Plate	1
6	63-00-4153	O-Ring	1	49	63-305F-034	Spring	1
7	63-I60S-201	Pulse Unit Housing	1	50	63-IS40S-502	F/R Valve	1
8	63-I40S-202	Bushing	1	51	63-00-41146	O-Ring	1
9	63-I40S-424	Washer	1	52	63-00-4121	O-Ring	1
10	63-I60S-401	Pulse Cylinder Seat	1	53	63-IS40S-312	Valve Washer	1
11	63-00-41127	O-Ring	3	54	63-00-3824	Steel Ball	1
12	63-00-41113	O-Ring	3	55	63-IS40S-313	Spring	1
13	63-I70-410	Greasing Screw	1	56	63-IS40S-311	Valve	1
14	63-00-3318	Spring Pin	2	57	63-00-41125	O-Ring	1
15EA	63-I40S-403-B	Front Cover	1	58	63-I40S-309	Seat	1
16	63-00-2602	X-Ring	1	59	63-00-0507	Screw	1
17	63-I40S-408	Front Plate	1	60	63-I40S-503	Regulator Knob	1
18	63-00-3813	Steel Ball	4	61	63-I60S-101	Motor Housing	1
19B	63-IS60SD-405	Anvil	1	62	63-I40S-102	Hanger	1
20B	63-I60S-452	Roller	2	63	63-I40S-108	Bushing	2
21B	63-I60S-406-B	Drive Blade	2	64	63-00-3306	Spring Pin	1
22	63-I40S-407	Spring	2	65	63-I40S-509	Bushing	1
23B	63-IS40-450	Block Valve	1	66	63-IS40S-510	Pin	1
24	63-I40S-411	Valve Screw	1	67	63-I40S-504	Trigger	1
25EA	63-IS60S-412-C	Valve	1	68	63-I40S-103	Housing Rubber	1
26	63-00-41130	O-Ring	1	69	63-I40S-508	Bushing	1
27EA	63-IS60SD-425-C	Spring	1	70	63-305C-021	Valve Stem	1
28	63-00-3436	Pin	1	71	63-I40S-507	Spring	1
29C	63-I60S-404-B	Pulse Cylinder	1	72	63-I40S-601	Muffler	1
30	63-00-3435	Pin	2	73	63-I40S-603	Exhaust Deflector	1
31	63-00-3407	Pin	2		63-I40S-604A	Air Inlet 1/4"PF	
32EA	63-IS40S-415-C	Rear Plate	1	74	63-I40S-604B	Air Inlet 1/4"PT	1
33	63-I40S-423	Washer	1		63-I40S-604C	Air Inlet 1/4"NPT	
34C	63-00-41173	O-Ring	2	75	63-00-3509	Snap Ring	1
35C	63-IS40S-421	Pressure Valve	2	76C	63-I60S-453	Spring	1
36	63-IS60S-314	Shut Off Stem	1	77C	63-I40S-454	Block Cap	1
37	63-IS40S-317	Spring	1	78EA	63-I40-409	Back Up Ring	1
38	63-I40S-402	Lock Nut	1	※	63-IS60SDRK-E05A	Repair kit :Index No-	
39	63-I40S-306	Lock Nut	1			11(2);12(2);16;22(2); 26;	
40	63-00-2348	Ball Bearing	1	※	63-IS60SDSK-E05A	34C(2);78EA	
41	63-00-3324	Spring Pin	1			Service kit :Index No-	
42	63-I60S-302	Cylinder	1			17;20B(2);21B(2); 32EA;	
43	63-00-3326	Spring Pin	1	※	63-I60SD-400ASM	45(9); 55; 69; 70; 71	
					63-01-0505FL	Pulse Unit	
					63-Pulse Tool Fluid, 125ml	Accessories Kits Included	
						Pulse Tool Fluid, 125ml	