



**Recommendations for Maintenance:**

Please, note it is important to make sure the tool has clean, dry and lubricated air at the recommended pressure supplied to it. (Please consult the service manual for further instructions)

The pulse tool requires preventive maintenance like oil changes and have the parts inspected periodically. It is recommended to make the first preventive maintenance at 250,000 pulses-seconds or 6 months, which either one occurs first. The tool's performance should be evaluated. The oil needs to be changed. Inspect all the soft parts of the pulse unit (the soft parts are referenced as the "Repair Kit" - see parts list page 2). The Repair Kit includes all the necessary parts and it is recommend to be performed every six months (unless parts are in good condition). If the tool fails before the 250,000 pulses-seconds then the pulse unit needs to be rebuilt, with the "Repair Kit" and "Service Kit" (see parts list page 2).  
 Caution: prevailing torque, which makes that the tool start pulsing early, reduces the life of the Oil & O-rings of the pulse unit. A pulse-second is not every second the tool is running, only when it's "pulsing" and applying torque. On typical applications the tool should run down freely until fastener is snug and then the tool starts pulsing until it reaches the preset torque. When operating the tool on the fastener, start counting once the tool begins pulsing. You can use a watch with a second hand and time it until the tool shuts-off. Use the information to calculate how many pulse-seconds the tool performs per application each day. Then perform some basic math to calculate the tool's maintenance schedule. Use this formula.

**# Pulsing Seconds ÷ Total of Pulsing Time = No Cycles**

NOTE: Please include the rework, reverse, or retightening time is involve on the operation to calculate the accurate pulsing time. Here is an example:

Pulsing Time = 2 seconds  
 Pulses- seconds recommended = 250,000

**250,000 pulses-sec ÷ 2 sec = 125,000 cycles**

Using the information above, you can estimate the maintenance period for the tool by using this formula:

No of Fasteners	Pulsing Time per Fastener	No of Parts Assembled per Day	Calculation	Maintenance Period
7	2 seconds	300	125,000 / (300*7) = 59	59 days

Index No.	Part No.	Description	Q'ty	Index No.	Part No.	Description	Q'ty
1	63-757-026	Anvil Collar	1	40	63-I40S-305	Rear Plate	1
2	63-I40SD-419	Hold Spacer	1	41	63-00-2356	Ball Bearing	1
3	63-I40SD-418	Spring	1	42	63-I40S-310	Air Inlet Plate	1
4	63-I40SD-417	Quick Change Hold	1	43	63-305F-034	Spring	1
5	63-00-0610	Set Screw	1	44	63-I40S-502	F/R Valve	1
6	63-I30S-201	Pulse Unit Housing	1	45	63-00-41146	O-Ring	1
7	63-I40S-202	Bushing	1	46	63-00-41125	O-Ring	1
8	63-I40S-424	Washer	1	47	63-I40S-309	Seat	1
9	63-I30S-401	Pulse Cylinder Seat	1	48	63-I40S-101	Motor Housing	1
10	63-00-41110	O-Ring	2	49	63-00-0507	Screw	1
11	63-I30S-410	Greasing Screw	1	50	63-I40S-503	Regulator Knob	1
12C	63-00-41173	O-Ring	2	51	63-I40S-102	Hanger	1
13	63-00-3318	Spring Pin	2	52	63-I40S-509	Bushing	1
14	63-I30S-403	Front Cover	1	53	63-I40S-510	Pin	1
15	63-00-2604	X-Ring	1	54	63-I40S-504	Trigger	1
16	63-00-41113	O-Ring	1	55	63-00-3306	Spring Pin	1
17EB	63-I80-411	Valve Screw	1	56	63-I40S-108	Bushing	2
18D	63-IS40S-412-B	Valve	1	57	63-I40S-103	Housing Rubber	1
19	63-00-41130	O-Ring	1	58	63-00-41127	O-Ring	1
20	63-00-3435	Pin	2	59	63-I40S-508	Bushing	1
21	63-I30S-408	Front Plate	1	60	63-305C-021	Valve Stem	1
22	63-I30SD-405	Anvil	1	61	63-I40S-507	Spring	1
23	63-00-3813	Steel Ball	3	62	63-I40S-601	Muffler	1
24B	63-I40S-452	Roller	2	63	63-I40S-603	Exhaust Deflector	1
25B	63-I30S-406-B	Drive Blade	2		63-I40S-604A	Air Inlet 1/4"PF-19	
26	63-I30S-407	Spring	2	64	63-I40S-604B	Air Inlet 1/4"PT-19	1
27C	63-I30S-404-B	Pulse Cylinder	1		63-I40S-604C	Air Inlet 1/4"NPT-18	
28	63-00-3436	Pin	1	65	63-00-3509	Snap Ring	1
29	63-00-3407	Pin	2	66C	63-IS40S-421	Pressure Valve	1
30	63-I30S-415	Rear Plate	1	67C	63-I40S-453	Spring	1
31	63-I40S-423	Washer	1	68C	63-I40S-454	Block Cap	1
32	63-I30S-402	Lock Nut	1	69EB	63-I80-422	Back Up Ring	1
33	63-I40S-306	Lock Nut	1	※	63-I30SDSK-MZ	Service kit :Index No-	
34	63-00-2348	Ball Bearing	1			21; 24B(2); 25B(2); 30; 38(9)	
35	63-00-3324	Spring Pin	1			59; 60; 61	
36	63-I40S-302	Cylinder	1	※	63-I30SDRK-MZ	Repair kit :Index No-	
37	63-I40S-303	Rotor	1			10(2); 16; 15; 26(2); 12C(2); 19	
38	63-I40S-304	Rotor Blade	9	※	63-Pulse Tool Fluid, 125ml	Pulse Tool Fluid (125ml)	
39	63-00-3326	Spring Pin	1		63-Pulse Tool Fluid, 1000ml	Pulse Tool Fluid (1000ml)	
※	63-I30SD-400ASM	Pulse unit : Index No-					
		9, 10, 11, 12C, 13, 14, 15, 16, 17EB, 18D, 19, 20, 21, 22, 24B, 25B, 26, 27C, 28, 29, 30, 32, 66C, 67C, 68C, 69EB					